

salling

FLAD, FLAT BRØDRISTER, TOASTER

MODEL: YT-107B

VARENUMMER / ITEM NUMBER: 10255577

220-240V, 50 HZ, 900 WATT



BETJENINGSVEJLEDNING / INSTRUCTION MANUAL

Bemærk

GEM AL EMBALLAGE, ÆSKEN, PLASTIK OSV., INDTIL DU HAR KONTROLLERET, AT BRØDRISTEREN FUNGERER, SOM DEN SKAL.

Kontrollér, at brødristeren ikke er beskadiget. I tvivlstilfælde må du IKKE BRUGE DEN, men skal kontakte vores kundeservice eller den forretning, hvor du har købt den.

Af hensyn til sikkerheden skal al emballage (plastikposer, æsker, flamingo osv.) opbevares utilgængeligt for børn og dyr.

Kontrollér, at spændingen i elnettet svarer til den, der står på apparatets mærkeplade, før du tilslutter apparatet til stikkontakten. Det anbefales at bruge en stikkontakt med jordforbindelse.

Generelle sikkerhedsanvisninger

- Før apparatet tages i brug, skal det kontrolleres, at netspændingen er den samme som den, der er angivet i de tekniske data sidst i denne manual.
- Dette apparat er kun beregnet til indendørs brug. Det må ikke anvendes til erhvervsmæssig brug eller udendørs.
- Dette apparat kan anvendes af børn på 8 år eller derover og personer med nedsatte fysiske, sensoriske eller mentale evner eller manglende erfaring og viden, hvis de er under passende opsyn eller har fået instruktion i at anvende apparatet på en sikker måde og forstår de involverede farer. Børn må ikke lege med apparatet. Den rengøring og vedligeholdelse, der skal udføres af brugeren, må ikke udføres af børn, medmindre de er over 8 år gamle og under opsyn. Apparatet og dets ledning skal altid være uden for børns rækkevidde.
- Apparatet er ikke beregnet til at blive betjent ved hjælp af et tænd/sluk-ur eller et separat fjernbetjeningsystem.
- Efterlad aldrig apparatet uden opsyn, når det er i brug.
- Kontrollér jævnligt, at ledningen ikke er beskadiget. Hvis ledningen eller apparatet er beskadiget, må det ikke anvendes, men skal indleveres til en autoriseret reparatør.
- Apparatet må aldrig nedsænkes i vand eller anden væske i forbindelse med rengøring eller af andre årsager. Det må aldrig anbringes i opvaskemaskinen, bortset fra de dele, der er angivet i afsnittet Rengøring.
- Må ikke anvendes i nærheden af varmekilder.
- Stikket skal tages ud af stikkontakten, før apparatet rengøres.
- Reparationer skal udføres af en autoriseret reparatør.
- Brug ikke apparatet udendørs. Anbring det på et tørt sted.
- Lad det ikke være frit tilgængeligt.
- Brug ikke tilbehør, der ikke er anbefalet af producenten, da dette kan udgøre en risiko for brugeren og kan beskadige apparatet.
Brug kun originalt tilbehør og originale reservedele.

- Flyt aldrig apparatet ved at trække i ledningen. Pas på, at ledningen ikke hænger fast i noget for at undgå at falde. Undgå at vikle ledningen rundt om apparatet og at sno den.
- Anbring apparatet på en tilstrækkelig flad og stabil overflade for at forhindre, at det falder ned.
- Lad apparatet køle af før rengøring og opbevaring.
- Sørg for, at apparatet ikke kommer i berøring med letantændelige materialer såsom gardiner, tekstiler osv. mens det er tændt, da det kan forårsage brand. Der skal mindst være en meter mellem apparatet og brændbare materialer.
- Rengør ikke apparatet med metalredskaber eller slibende redskaber for at undgå risikoen for kortslutninger og beskadigelse af overfladernes finish.
- Undlad at tildække apparatet eller dets ventilationshuller, da dette kan medføre brand.

Særlige sikkerhedsanvisninger

- Denne enhed må kun berøres ved sidehåndtagene.
- Flyt ikke brødristeren, mens den er tændt.
- Den øverste rist kan forblive varm i flere minutter efter brug.
- Den udvendige overflade bliver varm under brug, så pas på ikke at røre den.
- Fjern bakken efter hver brug.
- Brug ikke brødristeren til optøning af fødevarer.

Betjening

- Sæt stikket i en stikkontakt med jordforbindelse.
- Første gang, brødristeren skal bruges, skal timerknappen drejes til maksimum uden brød på brødristeren. Brødristeren vil afgive lugt og røg. Det er normalt og vil forsvinde efter første brug.
- Læg brødet på risten. Der skal altid være 1 cm mellem hver skive brød for at undgå overophedning brødristeren.
- Drej timerknappen til den ønskede position. Varmelegemerne vil langsomt begynde at gløde.
- Efter den indstillede tid ringer en klokke, og brødristeren slukker automatisk.
- Du kan til enhver tid slukke brødristeren ved at dreje timerknappen til 0.

Timerens omtrentlige tilberedningstider:

- 1: 35 sekunder
- 2: 65 sekunder
- 3: 100 sekunder
- 4: 135 sekunder
- 5: 165 sekunder
- 6: 180 sekunder

Rengøring og vedligeholdelse:

- Tag stikket ud, og lad apparatet køle af, før du rengør det.
- Du må ikke nedsænke brødristeren i vand eller andre væsker.
Den udvendige overflade kan rengøres med en ren, fugtig klud.
- Hvis der fortsat er pletter, kan sæbevand anvendes, men det må ikke trænge ind i ventilationsåbningerne.
- Brug ikke slibende rengøringsmidler eller skarpe redskaber til at rengøre den udvendige overflade med.
- Krummebakken kan fjernes til rengøring. Det gøres ved at trække den ud af rillen. Når den er gjort ren og tørret, føres den forsigtigt ind i rillen igen.

Bemærk:

Hvis denne brugsanvisnings instruktioner vedr. brug og rengøring ikke overholdes, kan garantien helt eller delvist bortfalde.

Tekniske data:

Model: YT-107B

Varenr.: 10255577

Strømforsyning: 220-240 V, 50 Hz

Effekt: 900 W

Dette udstyr er godkendt i overensstemmelse med alle EU-direktiver (CE, RoHS) samt retningslinjer for elektromagnetisk kompatibilitet og lavspændingsapparater og er konstrueret i overensstemmelse med sikkerhedsforskrifterne.

Bortskaffelse af udtjente elektriske apparater

EU-direktiv 2002/96/EF om affald af elektrisk og elektronisk udstyr (WEEE) kræver, at udtjente elektriske apparater til husholdningsbrug ikke må bortskaffes sammen med normalt usorteret husholdningsaffald.

Udtjente apparater skal indsamles separat for at optimere genvinding og genanvendelse af de materialer, de indeholder, og mindske indvirkningen på menneskers sundhed og miljøet. "Skraldespand"-symbolet med et kryds over på produktet minder dig om din forpligtelse til, at når du bortskaffer apparatet, skal det indsamles separat. Du kan spørge kommunen eller forhandleren om korrekt bortskaffelse udtjente apparater.



Caution

KEEP ALL PACKAGING, BOX, PLASTICS, ETC. UNTIL YOU CHECK THE GOOD OPERATION OF YOUR TOASTER.

Make sure your toaster is not damaged. In case of doubt, DO NOT USE IT and contact our after-sales service or the establishment where you purchased it. For safety, please keep all packaging (plastic bags, boxes, polystyrene, etc.) out of the reach of children or animals.

Before plugging the appliance into the mains supply, check that the voltage corresponds with that stated on the characteristics plate. The use of an earthed socket is recommended.

General security indication

- Before using the appliance, check that the mains voltage is same as the one on the characteristics or with the one indicated in the Technical Data at end of this manual.
- This appliance has been designed for indoor use only. Do not use it for professional or external purposes.
- This appliance may be used by children 8 years of age or older and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, if they have been given appropriate supervision or instruction regarding to the use of the appliance in a safe manner and understand the hazards involved. Children should not play with the appliance. The cleaning and maintenance to be performed by the user should not be performed by children unless they are over 8 years old and under supervision. Keep the appliance and its cord out of reach of children.
- The appliance is not intended to be operated by means of an external timer or a separate remote-control system.
- Never leave your appliance unattended when it is in use.
- Check regularly that the cable is not damaged. Do not use your appliance if the cord or appliance is damaged and take it to a qualified service technician.
- Never immerse the appliance in water or any other liquid, for cleaning or for any other reason. Never insert it in the dishwasher, except for the parts indicated in the Cleaning section.
- Do not use near heat sources.
- The power plug must be unplugged before cleaning the appliance.
- Any repairs should be performed by a qualified service technician.
- Do not use the appliance outdoors and place it in a dry place.
- Do not use attachments not recommended by the manufacturer, this may present a risk to the user and may damage the device. Use only original accessories and spare parts.

- Never move the appliance by pulling on the cord. Make sure that the cable does not get caught in any protrusions in order to avoid possible falls. Avoid twisting the cord around the appliance or twisting it around.
- Place the appliance on a sufficiently flat and stable surface to prevent it from falling.
- Let the appliance cool down before cleaning and storing.
- Ensure that the appliance does not come into contact with easily flammable materials such as curtains, fabrics, etc. When it is in operation, as it could cause a fire. Leave a minimum distance of one meter between the apparatus and flammable materials.
- Do not clean the appliance with metal or abrasive utensils to avoid the risk of short circuits and damage the surfaces of the finish.
- Do not cover the appliance or its ventilation holes as this could result in a fire.

Special safety instructions

- This device should only be touched by the side handles.
- Do not move your toaster while it is running.
- The top rack may remain hot minutes after last use.
- The exterior surface heats up during operation, be careful not to touch it.
- Remove the tray after each use.
- Do not use your toaster to defrost food.

Use

- Insert the plug into a grounded plug.
- During the first use, turn the timer knob to maximum without bread on the grill. Your toaster will emit smell and smoke, this is normal and will disappear after this first use.
- Put the bread on the rack. Always leave a 1cm gap between each slice, to avoid overheating your toaster.
- Turn the timer knob to the desired position. The resistors will light up slowly.
- After the set time, a bell will sound, and your toaster will turn off automatically.
- You can interrupt toasting at any time by turning the timer knob to 0.

Timer approximately run-time:

- 1: 35 seconds
- 2: 65 seconds
- 3: 100 seconds
- 4: 135 seconds
- 5: 165 seconds
- 6: 180 seconds

Cleaning and maintenance:

- Unplug and allow to cool before cleaning your toaster.
- Do not immerse your toaster in water or any liquid. The exterior surface can be cleaned with a clean, damp cloth.
- If stains continue to occur, soapy water can be used, preventing them from entering through the ventilation slots.
- Do not use abrasive cleaners or sharp utensils to clean the exterior surface.
- The pickup tray can be removed for cleaning. To do this pull the lower groove out. Once clean and dry, carefully insert it into its slot.

Attention

Failure to follow the recommendations for use and cleaning of this manual may result in partial or total loss of warranty.

Technical data:

Model: YT-107B

Item number: 10255577

Power supply: 220-240V, 50Hz

Power: 900W

This device has been approved in accordance with all EU directives (CE, RoHS) as well as electromagnetic compatibility and low voltage guidelines, and has been built in accordance with safety regulations.

Disposal of old electrical appliances.

The European directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal unsorted municipal waste stream.

Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The crossed out "wheeled bin" symbol on the product reminds you of your obligation, that when you dispose of the appliance, it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance.



Kontakt info/Contact info:
F&H of Scandinavia A/S
Gl. Skivevej 70, 8800 Viborg, Denmark Tlf: +45 8928 1300
www.fh-as.dk
Made in China