

salling



INSTRUCTION MANUAL KETTLE

11314640

INTRODUKTION

Mange tak fordi du har valgt et produkt fra Salling. Dermed har du erhvervet et kvalitetsprodukt som opfylder alle gældende krav til præstation og sikkerhedsstandarder i EU. For at sikre en korrekt behandling og en lang levetid anbefaler vi, at du overholder nedenstående anvisninger.

Du bedes læse vejledningen og især sikkerheds anvisningerne omhyggeligt igennem, inden du tager produktet i brug. Opbevar denne betjeningsvejledning, og overlad altid kun produktet til andre sammen med betjeningsvejledningen.

GENERELLE SIKKERHEDSFORANSTALTNINGER

- Forkert brug af produktet kan medføre personskade og beskadige produktet.
- Anvend kun produktet til det, det er beregnet til. Producenten er ikke ansvarlig for skader, der opstår som følge af forkert brug eller håndtering.
- Anbring altid produktet på et tørt, plant og stabilt underlag på god afstand af bordkant eller lignende.
- Produktet er udelukkende beregnet til husholdningsbrug. Produktet må ikke anvendes til erhvervsbrug.
- Produktet må kun sluttes til 220-240V~, 50-60Hz.
- Produktets motordel/elektronik, ledning og stikket må ikke nedsænkes i vand, og der må ikke trænge vand i motordel/elektronik.
- Rør aldrig ved produktet, ledningen eller stikkontakten med våde eller fugtige hænder.
- Udsæt ikke produktet for direkte sollys, høje temperaturer, fugt, støv eller ætsende stoffer.
- Forlad aldrig produktet, når det er tændt.
- Når produktet er i brug, bør det holdes under konstant opsyn.
- Når produktet bruges skal børn der opholder sig i nærheden af

den altid holdes under opsyn.

- Børn må ikke lege med produktet.
- Produktet kan indeholde skarpe dele og bør derfor opbevares utilgængeligt for børn.
- Brug kun tilbehør, der følger med produktet eller er anbefalet af producenten.
- Produktet må kun anvendes sammen med medfølgende base.
- Undgå at spilde vand på basen.
- Overstigning af max vandstand kan forårsage udskydning af kogende vand.
- Fjern ikke låget mens vandet koger.
- På modeller med aftageligt låg, skal man sørge for at låget sidder korrekt så evt. damp ledes væk fra håndtaget.
- Varmelegemet kan være meget varmt efter brug grundet restvarme.
- Produktet må bruges af børn på 8 år eller derover og personer med reducerede fysiske, sensoriske eller mentale evner, eller som mangler erfaring og viden, hvis de er under opsyn eller har modtaget instruktion i sikker brug af produktet og forstår de involverede farer.
- Hold produktet og ledningen uden for rækkevidden af børn under 8 år.
- Rengøring og vedligeholdelse må ikke udføres af børn med mindre de er ældre end 8 år og under opsyn.

LEDNING OG STIK

- Lad ikke ledningen hænge ud over bordkanten.
- Hold ledningen og produktet væk fra varmekilder, varme genstande og åben ild.
- Tag stikket ud af stikkontakten før rengøring, og hvis produktet ikke er i brug. Undlad at trække i ledningen, når du tager stikket ud af stikkontakten, men tag fat om selve stikket.
- Sørg for, at ledningen er rullet helt ud.
- Kontrollér jævnligt, om ledningen eller stikket er beskadiget, og brug ikke produktet, hvis dette er tilfældet, eller hvis det har været

tabt på gulvet, tabt i vand eller er blevet beskadiget på en anden måde.

- Hvis produktet, ledningen eller stikket er beskadiget, skal produktet efterses og om nødvendigt repareres af en autoriseret reparatør. Forsøg aldrig at reparere produktet selv. Kontakt købsstedet, hvis der er tale om en reparation, der falder ind under reklamationsretten. Hvis der foretages uautoriserede indgreb i produktet, bortfalder reklamationsretten.

REKLAMATIONSRETEN GÆLDER IKKE:

- Hvis ovennævnte ikke iagttages.
- Hvis der har været foretaget uautoriserede indgreb i produktet.
- Hvis produktet har været misligholdt, udsat for en voldsom behandling eller lidt anden form for overlast.

BORTSKAFFELSE AF PRODUKTET

Brugte produkter må ikke smides i husholdningsaffaldet. Iht. lovforskrifterne skal det udtjente produkt bortskaffes på ordentlig vis. Derved genanvendes de brugbare materialer, og miljøet skånes. Nærmere informationer fås hos den ansvarlige kommunale myndighed eller det lokale bortskaffelsesfirma. Produktet er forsynet med følgende logo:



Apparatet er kun beregnet til husholdningsbrug og må ikke anvendes til erhvervsmæssig brug.

PRODUKTBEKRIVELSE



FØR FØRSTE BRUG

Hæld rent vand i kedlen op til maksimumslinjen. Kog vandet, og tøm derefter kedlen. Gentag proceduren to til tre gange. Tør ydersiden af kedlen af med en fugtig klud.

BEMÆRK: Kedlens maksimale rumindhold er 1,7 liter.

SÅDAN BRUGER DU DIN KEDEL

1. Sørg for, at stikket er trukket ud af stikkontakten, før du hæl der vand på kedlen.
 2. Åbn låget ved at trykke på udløserknappen til låget.
 3. Hæld den ønskede mængde vand på kedlen, og sørg for, at vandstanden er mellem minimums- og maksimumsmærket.
 4. Luk låget helt i.
 - Hvis der er for lidt vand i kedlen, slukker den, før vandet koger..
 - Hæld ikke vand på kedlen over maksimumslinjen, da kogende vand kan sprøjte ud af tuden.
 - Sørg for, at låget er ordentligt lukket, før stikket til kedlen sættes i en stikkontakt.
 5. Anbring kedlen på foden.
- BEMÆRK: Sørg for, at du ikke spilder vand på foden.
6. Sæt strømkablet i en stikkontakt. Tryk ned på kontakten-Kontrollampen tænder, og kedlen begynder at koge. Kedlen slukker automatisk, når vandet koger.

- Hvis du skal koge mere vand, skal du vente ca. 30 sekunder, før du igen trykker på kontakten.
- Du kan også stoppe kogningen ved at slukke kedlen eller trække stikket ud af stikkontakten.

BEMÆRK: Kontrollér, at kontakten ikke er blokeret af forhindringer, og at låget er lukket korrekt. Kedlen slukker muligvis ikke automatisk, hvis kontakten er blokeret, eller låget er åbent.

7. Træk stikket til kedlen ud af stikkontakten, når vandet har kogt, før du hælder vand ud.

BEMÆRK: Ver forsigtig, når du hælder vand ud-Kogende vand kan forårsage skoldning.

Abn ikke låget, mens vandet er varmt.

8. Træk altid stikket til kedlen ud af stikkontakten, når kedlen ikke bruges.

BESKYTTELSE MOD TØRKOGNING

Hvis du ved et uheld tænder kedlen uden vand, slukker beskyttelsen mod tørkogning automatisk for strømmen. I dette tilfælde skal du lade kedlen køle af, før du hælder koldt vand på den.

RENGØRING OG VEDLIGEHOLDELSE

1. Træk altid strømkablet til apparatet ud af stikkontakten, og lad det afkøle fuldstændigt før rengøring.

BEMÆRK:

- Brug aldrig ætsende eller skurende rengøringsmidler eller skarpe genstande (såsom knive eller hårde børster) til at rengøre apparatet.
- Læg aldrig kedlen eller strømkablet ned i vand, og lad aldrig fugt komme i kontakt med disse dele.

2. Tør kedlens kabinet af med en fugtig klud.

BEMÆRK: Hvis indersiden af kanden er blevet kraftigt misfarvet, er den bedste måde at rengøre den på at bruge en fugtig klud og lidt vaskesoda.

FJERNELSE AF KALK

Dette apparat har et integreret varmelegeme, som forhindrer kalkaflejninger; derfor er afkalkning normalt unødvendig. Hvis du alligevel ønsker at afkalke den, skal du følge trinnene nedenfor:

1. Fjern stikket og lad apparatet køle naturligt af.
2. Kedlen er udstyret med et afkalkningsfilter. Dette filter skal fjernes ved rengøring.
3. Fyld kedlen med eddikeopløsning op til MAX-stregen. Bring det i kog.
4. Hæld opløsningen ud, og fyld derefter rent vand på kedlen. Kog vandet, og hæld det ud. Gentag processen flere gange, indtil lugten af eddike forsvinder.

BEMÆRK: Brug aldrig ammoniak eller andre produkter til at fjerne kalk fra apparatet. Disse kan være skadelige for dit helbred.

TEKNISKE DATA

Artikelnr. 11314640
220-240V, 50/60Hz
1850-2200 Watt

PRODUCENT

Epiq ApS
Krøyer Kielbergs Vej 3, 3. th
8660 Skanderborg, Danmark
www.epiq.dk

Vi tager forbehold for trykfejl.

INTRODUCTION

Thank you for choosing a product from Salling. You have acquired a quality product which meets all applicable performance and safety standards in the EU. In order to ensure proper treatment and a long product life, we recommend that you comply with the instructions below.

Please read the manual and especially the safety instructions carefully before using the product. Keep this manual and provide it for referral along with the product when others are using it.

GENERAL SAFETY INSTRUCTIONS

- Improper use of the product can cause personal injury and damage.
- Only use the product for what it is intended. The manufacturer is not liable for damages arising from improper use or handling.
- Always place the product on a dry, flat and stable surface well away from table edge or similar.
- The product is intended for household use only. The product is not for professional use.
- The product may only be connected to 220-240V~, 50-60Hz.
- The product engine/electronics, cord or plug cannot be submerged in water, and no water may get in contact with the engine/electronics.
- Never touch the product, cord or plug with wet or damp hands.
- Do not expose the product to direct sunlight, high temperatures, humidity, dust or corrosive substances.
- Never leave the product when it is turned on.
- When the product is in use, it should be kept under constant supervision. Children should always be supervised when using the product to ensure that they do not play with the product. The product is not a toy.
- The product may have sharp parts and must, therefore, be kept

out of reach of children.

- Only use the accessories that come with the product or that are recommended by the manufacturer.
- The product may only be used with the supplied base.
- Avoid spilling water on the base.
- Exceeding the maximum water level may cause boiling water to be ejected.
- Do not remove the lid while the water is boiling.
- On models with a removable lid, make sure that the lid fits correctly so that any steam is directed away from the handle.
- The heating element can be very hot after use due to residual heat.
- This product can be used by children aged from 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the product in a safe way and understand the hazards involved.
- Keep the product and its cord out of reach of children less than 8 years of age.
- Cleaning and user maintenance shall not be made by children without supervision.

CORD AND PLUG

- Do not let the cord hang over the edge.
- Keep the cord and the product away from heat sources, hot objects and open flames.
- Unplug the power cord before cleaning and if the product is not in use. Do not pull the cord when removing the plug from the socket, rather grasp the plug itself.
- Make sure that the cord is fully extended.
- Check regularly that the cord and the plug are not damaged and do not use the product if this is the case, or if it has been dropped on the floor, dropped in water or damaged in another way.
- If the product or plug is damaged, the product must be

inspected and, if necessary, repaired by an authorised repairer. Never try to repair the product yourself. Please, contact the store to see if there is a repair that falls under warranty. Tampering of the product will void the warranty.

RULES OF COMPLAINTS THE WARRANTY DOES NOT APPLY:

- If the above is not observed.
- If there has been unauthorised intervention of the product.
- If the product has been mishandled, subjected to rough treatment or some other form of damage.

PRODUCT DISPOSAL

Used product should not be disposed as household waste. According to legislation, the product should be disposed of properly so that the materials can be recycled in an environmentally friendly manner. Further information is available from the responsible local authority or local disposal company. The product is equipped with the following logo:



The appliance is intended only for domestic use, not for professional use.

PRODUCT DESCRIPTION



BEFORE FIRST USE

Fill the kettle with clean water up to the maximum fill line. Boil the water and then empty the kettle.

Repeat this process two to three times. Wipe the exterior surface with a damp cloth.

NOTE: The maximum capacity of the kettle is 1.7 L.

USEING YOUR KETTLE

1. Before filling the kettle, make sure the power plug is unplugged.
2. Open the lid by pressing the lid release button.
3. Fill the kettle with the desired amount of water, ensuring the water level is between the Min and Max marking.
4. Close the lid securely.

Note:

- Too little water may cause the kettle to switch off before reaching boiling point.
 - Do not fill the kettle above the maximum level, as boiling water may spill out of the spout.
 - Ensure the lid is firmly closed before plugging the kettle into a power outlet.
5. Place the kettle steadily on the base.

Note: Make sure that you do not spill any water on the base.

6. Plug the power cord into an outlet. Press the power switch down—the indicator light will turn on, and the kettle will begin to boil. The kettle will automatically switch off once the water has boiled.
- If you need to re-boil the water, wait about 30 seconds before pressing the switch again.
- You can also halt boiling by turning off or unplugging the kettle.

NOTE: Make sure the switch is free of obstructions and the lid is properly closed. The kettle may not switch off automatically if the switch is blocked or the lid is open.

7. After boiling, unplug the kettle before pouring the water.

NOTE: Pour with care-boiling water can cause scalds. Do not open the lid while the water is hot.

8. Always unplug the kettle when not in use.

OVERHEATING SAFEGUARD

The kettle is fitted with an overheating safeguard. This will switch off the kettle if it is operated without (sufficient) water. Allow the kettle to cool down for at least 10 minutes before using it again.

CLEANING AND MAINTENANCE

1. Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.

Note:

- Never use corrosive or scouring cleaning agents or sharp objects (such as knives or hard brushes) to clean the appliance.
 - Never immerse the kettle or power cord in water, and avoid letting moisture come into contact with these parts.
2. Wipe the body of the kettle with a damp cloth.

Note: If the interior of the jug has become severely discoloured, the best way to clean it is with a damp cloth and a little washing soda.

REMOVAL OF MINERAL DEPOSITS

This appliance features an integral heating element, preventing limescale buildup; therefore, descaling is generally unnecessary. If you wish to descale it anyway, follow the steps below:

1. Remove the plug and let the appliance cool down naturally.
 2. The kettle is fitted with a descaling filter. This filter must be removed for cleaning.
 3. Fill the kettle with vinegar solution up to the MAX line. Bring it to a boil.
 4. Discard the vinegar, then fill the kettle with clean water. Boil the water and discard it.
- Repeat this process several times until the vinegar smell disappears.

Note: Never use ammonia or other products to descale the appliance. These can be injurious to your health.

TECHNICAL DATA

Article No. 11314640
220-240V, 50/60Hz
1850-2200 Watt

PRODUCER

Epiq ApS
Krøyer Kielbergs Vej 3, 3. th
8660 Skanderborg, Denmark
www.epiq.dk

We cannot be held responsible for any printing errors.