

KØKKENCHEF



INSTRUCTION MANUAL FLAT TOASTER

11165465

INTRODUKTION

Mange tak fordi du har valgt et produkt fra Køkkenchef. Dermed har du erhvervet et kvalitetsprodukt som opfylder alle gældende krav til præstation og sikkerhedsstandarder i EU. For at sikre en korrekt behandling og en lang levetid anbefaler vi, at du overholder nedenstående anvisninger.

Du bedes læse vejledningen og især sikkerheds anvisningerne omhyggeligt igennem, inden du tager produktet i brug. Opbevar denne betjeningsvejledning, og overlad altid kun produktet til andre sammen med betjeningsvejledningen.

GENERELLE SIKKERHEDSFORANSTALTNINGER

- Forkert brug af produktet kan medføre personskade og beskadige produktet.
- Anvend kun produktet til det, det er beregnet til. Producenten er ikke ansvarlig for skader, der opstår som følge af forkert brug eller håndtering.
- Anbring altid produktet på et tørt, plant og stabilt underlag på god afstand af bordkant eller lignende.
- Produktet er udelukkende beregnet til husholdningsbrug. Produktet må ikke anvendes til erhvervsbrug.
- Produktet må kun sluttes til 220-240V~, 50/60Hz.
- Produktets motordel/elektronik, ledning og stikket må ikke nedsænkes i vand, og der må ikke trænge vand i motordel/elektronik.
- Rør aldrig ved produktet, ledningen eller stikkontakten med våde eller fugtige hænder.
- Udsæt ikke produktet for direkte sollys, høje temperaturer, fugt, støv eller ætsende stoffer.
- Forlad aldrig produktet, når det er tændt.
- Når produktet er i brug, bør det holdes under konstant opsyn.
- Når produktet bruges skal børn der opholder sig i nærheden af

den altid holdes under opsyn.

- Børn må ikke lege med produktet.
- Produktet kan indeholde skarpe dele og bør derfor opbevares utilgængeligt for børn.
- Brug kun tilbehør, der følger med produktet eller er anbefalet af producenten.
- Produktet må bruges af børn på 8 år eller derover og personer med reducerede fysiske, sensoriske eller mentale evner, eller som mangler erfaring og viden, hvis de er under opsyn eller har modtaget instruktion i sikker brug af produktet og forstår de involverede farer.
- Hold produktet og ledningen uden for rækkevidden af børn under 8 år.
- Rengøring og vedligeholdelse må ikke udføres af børn med mindre de er ældre end 8 år og under opsyn.

LEDNING OG STIK

- Lad ikke ledningen hænge ud over bordkanten.
- Hold ledningen og produktet væk fra varmekilder, varme genstande og åben ild.
- Tag stikket ud af stikkontakten før rengøring, og hvis produktet ikke er i brug. Undlad at trække i ledningen, når du tager stikket ud af stikkontakten, men tag fat om selve stikket.
- Sørg for, at ledningen er rullet helt ud.
- Kontrollér jævnligt, om ledningen eller stikket er beskadiget, og brug ikke produktet, hvis dette er tilfældet, eller hvis det har været tabt på gulvet, tabt i vand eller er blevet beskadiget på en anden måde.
- Hvis produktet, ledningen eller stikket er beskadiget, skal produktet efterses og om nødvendigt repareres af en autoriseret reparatør. Forsøg aldrig at reparere produktet selv. Kontakt købsstedet, hvis der er tale om en reparation, der falder ind under reklamationsretten. Hvis der foretages uautoriserede indgreb i produktet, bortfalder reklamationsretten.

REKLAMATIONSRETEN GÆLDER IKKE:

- Hvis ovennævnte ikke iagttages.
- Hvis der har været foretaget uautoriserede indgreb i produktet.
- Hvis produktet har været misligholdt, udsat for en voldsom behandling eller lidt anden form for overlast.

BORTSKAFFELSE AF PRODUKTET

Brugte produkter må ikke smides i husholdningsaffaldet. Iht. lovforskrifterne skal det udtjente produkt bortskaffes på ordentlig vis. Derved genanvendes de brugbare materialer, og miljøet skånes. Nærmere informationer fås hos den ansvarlige kommunale myndighed eller det lokale bortskaffelsesfirma. Produktet er forsynet med følgende logo:



BESKRIVELSE

1. Krummebakke
2. Timer
3. Kontrol LED
4. Tænd knap
5. Sluk knap



FORSIGTIG

Fyld aldrig hele risten med brød. Efterlad 1 cm. Mellem brødsiverne.

SIKKERHEDSINSTRUKTIONER

For at undgå brand, efterlad ikke brødristeren uden opsyn under brug.

Rengør for krummer jævnlgt for at undgå risici for brand eller at brødristeren bliver beskadiget.

Brød kan brænde under ristningen af brødet. Hold altid øje med dette.

Når apparatet tændes for første gang, indstil da apparatet til sin maksimale indstilling, men uden brød på risten. Gør dette to gange for at afbrænde al overskydende lugt. Tænd apparatet ved at indstille den ønskede ristningstid og tryk på tænd knappen.

Lampen vil lyse, hvilket indikerer at apparatet er startet. Når den indstillede tid er nået vil apparatet automatisk slukke, lampen vil slukke og der vil høres en lyd.

Ristningen kan afsluttes når som helst ved at trykke på sluk knappen.

INDSTILLING

Drej knappen på den ønskede indstilling, og tryk på startknappen.

1- Korteste ristningstid

6- Længste ristningstid

TYPER AF BRØD

Takket være apparatets design kan den anvendes til at riste alle typer brød, inklusiv produkter som croissanter og andet bagværk.

RENGØRING

Sørg for at stikket er trukket ud af stikkontakten og at apparatet er helt afkølet.

Rengør ydresiden af apparatet med en fugtig klud. Lad aldrig vand komme ind i apparatet, og indsæt aldrig metalgenstande i risten. Anvend aldrig skrappe rengøringsmidler.

FJERNELSE AF KRUMMER

Åben krummebakken og fjern alle brødrester.

VIGTIGT: Træk altid stikket ud af stikkontakten før dette gøres.

REPARATIONER

Bliver apparatet defekt, anbefaler vi at det tages med til et autoriseret servicecenter.

TEKNISKE DATA

Artikelnr. 11165465
220-240V~, 50/60Hz
600 Watt

PRODUCENT

Epiq ApS
Krøyer Kielbergs Vej 3, 3. th
8660 Skanderborg, Danmark
www.epiq.dk

Vi tager forbehold for trykfejl.

INTRODUCTION

Thank you for choosing a product from Køkkenchef. You have acquired a quality product which meets all applicable performance and safety standards in the EU. In order to ensure proper treatment and a long product life, we recommend that you comply with the instructions below.

Please read the manual and especially the safety instructions carefully before using the product. Keep this manual and provide it for referral along with the product when others are using it.

GENERAL SAFETY INSTRUCTIONS

- Improper use of the product can cause personal injury and damage.
- Only use the product for what it is intended. The manufacturer is not liable for damages arising from improper use or handling.
- Always place the product on a dry, flat and stable surface well away from table edge or similar.
- The product is intended for household use only. The product is not for professional use.
- The product may only be connected to 220-240V~, 50/60Hz.
- The product engine/electronics, cord or plug cannot be submerged in water, and no water may get in contact with the engine/electronics.
- Never touch the product, cord or plug with wet or damp hands.
- Do not expose the product to direct sunlight, high temperatures, humidity, dust or corrosive substances.
- Never leave the product when it is turned on.
- When the product is in use, it should be kept under constant supervision. Children should always be supervised when using the product to ensure that they do not play with the product. The product is not a toy.
- The product may have sharp parts and must, therefore, be kept

out of reach of children.

- Only use the accessories that come with the product or that are recommended by the manufacturer.
- This product can be used by children aged from 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the product in a safe way and understand the hazards involved.
- Keep the product and its cord out of reach of children less than 8 years of age.
- Cleaning and user maintenance shall not be made by children without supervision.

CORD AND PLUG

- Do not let the cord hang over the edge.
- Keep the cord and the product away from heat sources, hot objects and open flames.
- Unplug the power cord before cleaning and if the product is not in use. Do not pull the cord when removing the plug from the socket, rather grasp the plug itself.
- Make sure that the cord is fully extended.
- Check regularly that the cord and the plug are not damaged and do not use the product if this is the case, or if it has been dropped on the floor, dropped in water or damaged in another way.
- If the product or plug is damaged, the product must be inspected and, if necessary, repaired by an authorised repairer. Never try to repair the product yourself. Please, contact the store to see if there is a repair that falls under warranty. Tampering of the product will void the warranty.

RULES OF COMPLAINTS THE WARRANTY DOES NOT APPLY:

- If the above is not observed.
- If there has been unauthorised intervention of the product.
- If the product has been mishandled, subjected to rough

treatment or some other form of damage.

PRODUCT DISPOSAL

Used product should not be disposed as household waste. According to legislation, the product should be disposed of properly so that the materials can be recycled in an environmentally friendly manner. Further information is available from the responsible local authority or local disposal company. The product is equipped with the following logo:



DESCRIPTION

1. Crumb tray
2. Browning control knob
3. Control LED
4. On button
5. Off button



CAUTION

Never fill the rack completely with bread, leave a free space of 1 cm between the slices.

SAFETY INSTRUCTIONS:

To avoid possibility of fire, do not leave toaster unattended during use.

Clean out accumulated crumbs frequently to avoid risk of fire or toaster malfunction

Bread may burn during toasting the bread. This must be watch.

When switching the toaster on for the first time, set the toaster to its maximum setting but without any bread

in it. Do this twice in order to burn off any residual smells. To switch it on, set the timer to the desired position

and press the ON switch.

The pilot lamp will light up, indicating that the appliance is working. When it reaches the set time, the

appliance will automatically switch off, along with the pilot lamp and a buzzer will sound.

Toasting can be interrupted at any time by pressing the OFF switch.

TOAST SETTING CONTROL:

Turn the selector to the desired setting and press the start button.

1- Shortest toasting time.

6- Longest toasting time.

TYPES OF BREAD:

Thanks to its design the toaster accepts all types of sliced bread, including products such as croissants and pastries. The selected task setting may vary depending on the water content of the bread that you are using.

CLEANING

Check that the appliance is unplugged from the mains and completely cold.
Clean the outer casing with a damp cloth. Never let water get inside the toaster, or insert any metal objects in through the bread slot. Never use abrasive cleaning products.

CRUMB REMOVAL

Open the crumb catcher tray and remove the contents.

IMPORTANT: Always unplug the toaster from the mains before doing this.

REPAIRS

Should the appliance become defective, do not hesitate in taking it along to an authorized technical service center.

TECHNICAL DATA

Article No. 11165465
220-240V~, 50/60Hz
600 Watt

PRODUCER

Epiq ApS
Krøyer Kielbergs Vej 3, 3. th
8660 Skanderborg, Denmark
www.epiq.dk

We cannot be held responsible for any printing errors.