

salling



INSTRUCTION MANUAL FOOT WARMER

11088815

INTRODUKTION

Mange tak fordi du har valgt et produkt fra Salling. Dermed har du erhvervet et kvalitetsprodukt som opfylder alle gældende krav til præstation og sikkerhedsstandarder i EU. For at sikre en korrekt behandling og en lang levetid anbefaler vi, at du overholder nedenstående anvisninger.

Du bedes læse vejledningen og især sikkerheds anvisningerne omhyggeligt igennem, inden du tager produktet i brug. Opbevar denne betjeningsvejledning, og overlad altid kun produktet til andre sammen med betjeningsvejledningen.

GENERELLE SIKKERHEDSFORANSTALTNINGER

- Forkert brug af produktet kan medføre personskade og beskadige produktet.
- Anvend kun produktet til det, det er beregnet til. Producenten er ikke ansvarlig for skader, der opstår som følge af forkert brug eller håndtering.
- Anbring altid produktet på et tørt, plant og stabilt underlag på god afstand af bordkant eller lignende.
- Produktet er udelukkende beregnet til husholdningsbrug. Produktet må ikke anvendes til erhvervsbrug.
- Produktet må kun sluttes til 220-240V~, 50/60Hz.
- Produktets motordel/elektronik, ledning og stikket må ikke nedsænkes i vand, og der må ikke trænge vand i motordel/elektronik.
- Rør aldrig ved produktet, ledningen eller stikkontakten med våde eller fugtige hænder.
- Udsæt ikke produktet for direkte sollys, høje temperaturer, fugt, støv eller ætsende stoffer.
- Forlad aldrig produktet, når det er tændt.
- Når produktet er i brug, bør det holdes under konstant opsyn.
- Når produktet bruges skal børn der opholder sig i nærheden af

den altid holdes under opsyn.

- Børn må ikke lege med produktet.
- Produktet kan indeholde skarpe dele og bør derfor opbevares utilgængeligt for børn.
- Brug kun tilbehør, der følger med produktet eller er anbefalet af producenten.
- Produktet må ikke bruges af personer med nedsat følsomhed, fysiske eller mentale handicap, eller personer, som ikke er i stand til at betjene produktet, medmindre de overvåges eller instrueres i brugen af en person, som er ansvarlig for deres sikkerhed.

LEDNING OG STIK

- Lad ikke ledningen hænge ud over bordkanten.
- Hold ledningen og produktet væk fra varmekilder, varme genstande og åben ild.
- Tag stikket ud af stikkontakten før rengøring, og hvis produktet ikke er i brug. Undlad at trække i ledningen, når du tager stikket ud af stikkontakten, men tag fat om selve stikket.
- Sørg for, at ledningen er rullet helt ud.
- Kontrollér jævnligt, om ledningen eller stikket er beskadiget, og brug ikke produktet, hvis dette er tilfældet, eller hvis det har været tabt på gulvet, tabt i vand eller er blevet beskadiget på en anden måde.
- Hvis produktet, ledningen eller stikket er beskadiget, skal produktet efterses og om nødvendigt repareres af en autoriseret reparatør. Forsøg aldrig at reparere produktet selv. Kontakt købsstedet, hvis der er tale om en reparation, der falder ind under reklamationsretten. Hvis der foretages uautoriserede indgreb i produktet, bortfalder reklamationsretten.

REKLAMATIONSRETEN GÆLDER IKKE:

- Hvis ovennævnte ikke iagttages.
- Hvis der har været foretaget uautoriserede indgreb i produktet.
- Hvis produktet har været misligholdt, udsat for en voldsom behandling eller lidt anden form for overlast.

BORTSKAFFELSE AF PRODUKTET

Brugte produkter må ikke smides i husholdningsaffaldet. Iht. lovforskrifterne skal det udtjente produkt bortskaffes på ordentlig vis. Derved genanvendes de brugbare materialer, og miljøet skånes. Nærmere informationer fås hos den ansvarlige kommunale myndighed eller det lokale bortskaffelsesfirma. Produktet er forsynet med følgende logo:



BETJENING

- Placer fodvarmeren udfoldet og fladt på gulvet, kontakten må ikke være inde i fodvarmeren og godt tilgængelig.
- Tilslut fodvarmeren med det aftagelige strømstik. Sæt netledningen i stikkontakten.
- Tag skoene af, før du bruger apparatet. Du kan beholde sokkerne på.
- Sæt dig behageligt ned og sæt fødderne ind i den bløde indvendige foring.
- Fodvarmeren opvarmes hurtigere, når du først indstiller temperaturen til højeste niveau.
- Vi anbefaler at vælge det lave temperaturniveau, når du bruger fodvarmeren i flere timer.
- Husk at slukke for apparatet efter brug.

TEMPERATURE SETTINGS

Indstilling	Funktion
 knap	Tænd eller sluk
1	1 niveau, lavt varmeniveau
2	2 niveau
3	3 niveau
4	4 niveau
5	5 niveau
6	6 niveau, højt varmeniveau



AUTOMATISK SIKKERHEDSSLUKNING

Fodvarmeren slukker automatisk efter 90 minutter. Hvis du vil tænde fodvarmeren igen, Du kan trykke på startknappen for at tænde for fodvarmeren igen, 1 niveau er standardindstillingen, når du tænder hver gang. Du kan derefter vælge det ønskede temperaturtrin.

VIGTIGT: SLUK FODVARMEREN, NÅR DU IKKE SKAL BRUGE VARME

Træk altid stikket ud af stikkontakten, når fodvarmeren ikke bruges.

Dæk den IKKE til med noget materiale, f.eks. en dyne, undgå at lægge pres på styreenheden.

RENGØRING OG PLEJE

- Træk altid stikket ud af stikkontakten, før du rengør den elektriske fodvarmer.
- Træk stikket ud af stikkontakten, og lad fodvarmeren køle helt af, før du vasker den.
- Afbryd kontrolenheden fra den elektriske fodvarmer ved stikket på undersiden.

VIGTIGT: Nedsænk aldrig ledningen eller kontrolenheden i vand eller andre væsker. Det kan medføre uoprettelige skader, der ikke dækkes af garantien.

- Vask fodvarmeren i hånden i vand på maksimalt 30 °C (anbefalet).
- Det anbefales ikke at vaske fodvarmerens ydre varmebetræk i en vaskemaskine. For at forlænge produktets levetid anbefales håndvask. Du kan også forsigtigt tørre overfladen af med en fugtig klud.
- Læg den elektriske fodvarmer til tørre på et vandsugende håndklæde eller en måtte. Sæt den aftagelige kontrolenhed på igen, når den elektriske fodvarmer er helt tør. Fodvarmeren kan kun betjenes med den medfølgende kontrolenhed.

OPBEVARING

- Fodvarmeren skal være helt tør, før den lægges væk.
- Slut IKKE fodvarmeren til strømforsyningen for at tørre puden.
- Tør den IKKE i solen, og stryg IKKE fodvarmeren. Det medfører sikkerhedsproblemer på grund af aldring af isoleringslaget.
- Opbevar fodvarmeren et rent og tørt sted. Anbring ingen genstande på fodvarmeren under opbevaring for at undgå knæk.
- Brug ikke mølbekæmpelsesmidler, såsom naftalin, da de beskadiger isoleringsmaterialet.

KONTROLLÉR:

At ledningen ikke udsættes for stærke påvirkninger, såsom bøjning, sammenkrølning, vridning eller træk, og at ledningen ikke kommer under tryk eller klemmes mellem skarpe genstande. Manglende overholdelse kan medføre elektrisk stød og udgøre en sikkerhedsrisiko. Ledningen skal altid hænge frit. Rul ledningen løst sammen under opbevaring af fodvarmeren, og sørg for ikke at vride eller klemme ledningen.

TEKNISKE DATA

Artikelnr. 11088815
220-240V~, 50/60Hz
100 Watt

PRODUCENT

Epiq ApS
Krøyer Kielbergs Vej 3, 3. th
8660 Skanderborg, Danmark
www.epiq.dk

Vi tager forbehold for trykfejl.

INTRODUCTION

Thank you for choosing a product from Salling. You have acquired a quality product which meets all applicable performance and safety standards in the EU. In order to ensure proper treatment and a long product life, we recommend that you comply with the instructions below.

Please read the manual and especially the safety instructions carefully before using the product. Keep this manual and provide it for referral along with the product when others are using it.

GENERAL SAFETY INSTRUCTIONS

- Improper use of the product can cause personal injury and damage.
- Only use the product for what it is intended. The manufacturer is not liable for damages arising from improper use or handling.
- Always place the product on a dry, flat and stable surface well away from table edge or similar.
- The product is intended for household use only. The product is not for professional use.
- The product may only be connected to 220-240V~, 50/60Hz.
- The product engine/electronics, cord or plug cannot be submerged in water, and no water may get in contact with the engine/electronics.
- Never touch the product, cord or plug with wet or damp hands.
- Do not expose the product to direct sunlight, high temperatures, humidity, dust or corrosive substances.
- Never leave the product when it is turned on.
- When the product is in use, it should be kept under constant supervision. Children should always be supervised when using the product to ensure that they do not play with the product. The product is not a toy.
- The product may have sharp parts and must, therefore, be kept

out of reach of children.

- Only use the accessories that come with the product or that are recommended by the manufacturer.
- The product must not be used by people with reduced sensitivity, physical or mental disability, or people who are not able to operate the product unless they are supervised or instructed by a person responsible for their safety.

CORD AND PLUG

- Do not let the cord hang over the edge.
- Keep the cord and the product away from heat sources, hot objects and open flames.
- Unplug the power cord before cleaning and if the product is not in use. Do not pull the cord when removing the plug from the socket, rather grasp the plug itself.
- Make sure that the cord is fully extended.
- Check regularly that the cord and the plug are not damaged and do not use the product if this is the case, or if it has been dropped on the floor, dropped in water or damaged in another way.
- If the product or plug is damaged, the product must be inspected and, if necessary, repaired by an authorised repairer. Never try to repair the product yourself. Please, contact the store to see if there is a repair that falls under warranty. Tampering of the product will void the warranty.


RULES OF COMPLAINTS THE WARRANTY DOES NOT APPLY:

- If the above is not observed.
- If there has been unauthorised intervention of the product.
- If the product has been mishandled, subjected to rough treatment or some other form of damage.

PRODUCT DISPOSAL

Used product should not be disposed as household waste. According to legislation, the product should be disposed of

properly so that the materials can be recycled in an environmentally friendly manner. Further information is available from the responsible local authority or local disposal company. The product is equipped with the following logo:



OPERATION

- Place the foot warmer unfolded and flat on the floor, the switch should be not inside of the foot warmer and well reachable.
- Connect the foot warmer with the detachable power connector. Plug the power cord into the mains outlet.
- Remove your shoes before using the appliance. You can keep your socks on.
- Take a seat comfortably and put your feet inside the soft inner lining.
- The foot warmer heats up quicker when you initially set the temperature to highest level.
- We recommend selecting the low temperature level when using the foot warmer for several hours.
- Remember to turn off the appliance after used.

TEMPERATURE SETTINGS

Setting	Function
 button	Turn on or turn off
1	1 level, low heat level
2	2 level
3	3 level
4	4 level
5	5 level
6	6 level, high heat level



AUTOMATICALLY SAFETY SWITCHED OFF

The heat pad is equipped with an automatic cutout. This switches the unit off after 90 minutes of operation. You can press the start button to switch the heat pad back on, 1 level is the default setting when you switch on each time. You can now select the desired temperature level.

IMPORTANT: SWITCH OFF THE FOOT WARMER WHEN YOU DO NOT NEED ANY HEATING
Always disconnect the power plug from the socket outlet when it is not in use.
DO NOT cover it with any material e.g. a quilt. Avoid applying pressure on the control unit.

CLEANING AND CARE

- Always disconnect the power plug from the socket outlet before cleaning the electric foot

warmer.

- Before washing, unplug it from the mains outlet and let it cool down completely.
- Unplug the control unit from the electric foot warmer using the connector on the underside.
- **IMPORTANT:** Never immerse the power cable or the control unit in water or liquid, it would cause irreparable damage not covered by warranty.
- Clean the foot warmer by hand wash at maximum 30 °C (recommended).
- Washing the outer heating cover of the foot warmer in a washing machine is not recommended. To prolong the product's lifespan, hand washing is advised. You may also gently wipe the surface with a damp cloth.
- To dry, lay the outer heating cover on a at moisture-absorbent towel or mat. When the outer heating cover is completely dry reconnect the detachable control unit. The foot warmer can only be operated with the provided control unit.

STORAGE

- Only store the foot warmer when it is completely dry.
- **DO NOT** connect the foot warmer to the power supply to dry it.
- **DO NOT** dry it in the sun or iron it. This will cause safety problems because of the aging of the insulating layer.
- Store the foot warmer in a clean and dry place. When storing, do not place any objects on the foot warmer to prevent bucking.
- Do not using any mothproofing agent such as Naphthalene as this will damage the insulation material.

ENSURE THAT

The power cord is not subjected to any excessive stress such as: bending, bunching, twisting, or pulling. The power cord should not be pressed or trapped against any sharp objects whatsoever. Failure to do so may result in an electrical shortage and pose a safety risk. The power cord should be allowed to hang freely at all times. When storing the foot warmer, loosely coil the power cord, being sure not to crimp or pinch the cord.

TECHNICAL DATA

Article No. 11088815
220-240V~, 50/60Hz
100 Watt

PRODUCER

Epiq ApS
Krøyer Kielbergs Vej 3, 3. th
8660 Skanderborg, Denmark
www.epiq.dk

We cannot be held responsible for any printing errors.