

salling



INSTRUCTION MANUAL HEATING BLANKET

11088814

INTRODUKTION

Mange tak fordi du har valgt et produkt fra Salling. Dermed har du erhvervet et kvalitetsprodukt som opfylder alle gældende krav til præstation og sikkerhedsstandarder i EU. For at sikre en korrekt behandling og en lang levetid anbefaler vi, at du overholder nedenstående anvisninger.

Du bedes læse vejledningen og især sikkerheds anvisningerne omhyggeligt igennem, inden du tager produktet i brug. Opbevar denne betjeningsvejledning, og overlad altid kun produktet til andre sammen med betjeningsvejledningen.

GENERELLE SIKKERHEDSFORANSTALTNINGER

- Forkert brug af produktet kan medføre personskade og beskadige produktet.
- Anvend kun produktet til det, det er beregnet til. Producenten er ikke ansvarlig for skader, der opstår som følge af forkert brug eller håndtering.
- Anbring altid produktet på et tørt, plant og stabilt underlag på god afstand af bordkant eller lignende.
- Produktet er udelukkende beregnet til husholdningsbrug. Produktet må ikke anvendes til erhvervsbrug.
- Produktet må kun sluttes til 220-240V~, 50/60Hz.
- Produktets motordel/elektronik, ledning og stikket må ikke nedsænkes i vand, og der må ikke trænge vand i motordel/elektronik.
- Rør aldrig ved produktet, ledningen eller stikkontakten med våde eller fugtige hænder.
- Udsæt ikke produktet for direkte sollys, høje temperaturer, fugt, støv eller ætsende stoffer.
- Forlad aldrig produktet, når det er tændt.
- Når produktet er i brug, bør det holdes under konstant opsyn.
- Når produktet bruges skal børn der opholder sig i nærheden af

den altid holdes under opsyn.

- Børn må ikke lege med produktet.
- Produktet kan indeholde skarpe dele og bør derfor opbevares utilgængeligt for børn.
- Brug kun tilbehør, der følger med produktet eller er anbefalet af producenten.
- Produktet må ikke bruges af personer med nedsat følsomhed, fysiske eller mentale handicap, eller personer, som ikke er i stand til at betjene produktet, medmindre de overvåges eller instrueres i brugen af en person, som er ansvarlig for deres sikkerhed.

LEDNING OG STIK

- Lad ikke ledningen hænge ud over bordkanten.
- Hold ledningen og produktet væk fra varmekilder, varme genstande og åben ild.
- Tag stikket ud af stikkontakten før rengøring, og hvis produktet ikke er i brug. Undlad at trække i ledningen, når du tager stikket ud af stikkontakten, men tag fat om selve stikket.
- Sørg for, at ledningen er rullet helt ud.
- Kontrollér jævnligt, om ledningen eller stikket er beskadiget, og brug ikke produktet, hvis dette er tilfældet, eller hvis det har været tabt på gulvet, tabt i vand eller er blevet beskadiget på en anden måde.
- Hvis produktet, ledningen eller stikket er beskadiget, skal produktet efterses og om nødvendigt repareres af en autoriseret reparatør. Forsøg aldrig at reparere produktet selv. Kontakt købsstedet, hvis der er tale om en reparation, der falder ind under reklamationsretten. Hvis der foretages uautoriserede indgreb i produktet, bortfalder reklamationsretten.

REKLAMATIONSRETEN GÆLDER IKKE:

- Hvis ovennævnte ikke iagttages.
- Hvis der har været foretaget uautoriserede indgreb i produktet.
- Hvis produktet har været misligholdt, udsat for en voldsom behandling eller lidt anden form for overlast.

BORTSKAFFELSE AF PRODUKTET

Brugte produkter må ikke smides i husholdningsaffaldet. Iht. lovforskrifterne skal det udtjente produkt bortskaffes på ordentlig vis. Derved genanvendes de brugbare materialer, og miljøet skånes. Nærmere informationer fås hos den ansvarlige kommunale myndighed eller det lokale bortskaffelsesfirma. Produktet er forsynet med følgende logo:



SYMBOLFORKLARING



Læs brugsanvisningen



Må ikke bleges



Må ikke stryges



Må ikke renses



Må ikke tørretumbles



Indsæt ikke stifter



Må ikke bruges foldet eller ujævnt



Håndvaskes, maksimal temp. 40 °C



Må ikke anvendes af små børn (0-3 år)

ELEKTRISK VARMEUNDERLAG

Må ikke anvendes på elevationssenge.

Placer underlaget på madrassen med strømkablet i hovedenden. Sørg for, at kontrolenheden kommer ud i toppen af underlaget, og at varmeelementerne ikke befinder sig i hovedenden.

Find elastiksnoren i hjørnet af sengen, så det elektriske varmeunderlag er godt udsprent omkring madrassens overflade. Det elektriske varmeunderlag fastgøres nu til madrassen, og det glattes ud, så der ikke er buller eller folder i underlaget. Sengen redes derefter som normalt.

**TÆND ALDRIG FOR VARMEUNDERLAGET, FØR DET ER FOLDET HELT UD.
GØRES DETTE ALLIGEVEL, KAN DET RESULTERE I UOPRETTETLIG SKADE PÅ
PRODUKTET.**

**UNDERLAGET VIL ALDRIG FØLES HELT VARMT, FØR DU LIGGER PÅ DET.
UNDERLAGETS TEMPERATURNIVEAU ER JUSTERBART FOR AT FORHINDRE
FORBRÆNDINGER.**

LÆG DIG IKKE UNDER UNDERLAGET.

BRUG AF UNDERLAGET

Temperaturtrin

Indstilling	Funktion
 knap	Tændersluk
1	1 niveau, lavt varmeniveau
2	2 niveau
3	3 niveau
4	4 niveau
5	5 niveau
6	6 niveau, højt varmeniveau

Det tager ca. 15 minutter for underlaget at nå den ønskede temperatur. Husk at en temperatur, der føles varm på hånden, kan føles ekstremt varm på andre dele af kroppen. Der vil måske opstå en svag lugt, den første gang underlaget varmes op. Sørg for at lufte ud i lokalet, efter underlaget har været opvarmet første gang.

Underlagets varmefunktion slukker automatisk efter 8 timer. Du kan trykke på startknappen for at tænde for varmepuden igen, 1 niveau er standardindstillingen, når du tænder hver gang. Du kan derefter vælge det ønskede temperaturtrin.

RENGØRING & VEDLIGEHOLD

RENGØRING

Underlaget kan håndvaskes ved en vandtemperatur under 40 °C.

Stryg IKKE underlaget.

Tør det IKKE ved hjælp af en tørretumbler.

Tør IKKE underlaget i direkte sollys.

Brug IKKE et apparat, fx en hårtørre til at tørre det.

Lad underlaget tørre naturligt.

Brug IKKE underlaget, hvis det er fugtigt eller vådt.

OPBEVARING

Når det ikke er i brug, så lad det afkøle, inden det foldes sammen, og fold så underlaget

forsigtigt sammen og læg det i den pose, det ankom i.
Sørg for, at underlaget er helt tørt, inden det foldes og pakkes væk. Underlaget skal hænges på et sted med god udluftning for at tørre naturligt.
Anvend ikke mølmidler på underlaget.
Lav ikke rynker i underlaget ved at sætte andre ting ovenpå det under opbevaring.

TEKNISKE DATA

Artikelnr. 11088814
220-240V~, 50/60Hz
100 Watt

PRODUCENT

Epiq ApS
Krøyer Kielbergs Vej 3, 3. th
8660 Skanderborg, Danmark
www.epiq.dk

Vi tager forbehold for trykfejl.

INTRODUCTION

Thank you for choosing a product from Salling. You have acquired a quality product which meets all applicable performance and safety standards in the EU. In order to ensure proper treatment and a long product life, we recommend that you comply with the instructions below.

Please read the manual and especially the safety instructions carefully before using the product. Keep this manual and provide it for referral along with the product when others are using it.

GENERAL SAFETY INSTRUCTIONS

- Improper use of the product can cause personal injury and damage.
- Only use the product for what it is intended. The manufacturer is not liable for damages arising from improper use or handling.
- Always place the product on a dry, flat and stable surface well away from table edge or similar.
- The product is intended for household use only. The product is not for professional use.
- The product may only be connected to 220-240V~, 50/60Hz.
- The product engine/electronics, cord or plug cannot be submerged in water, and no water may get in contact with the engine/electronics.
- Never touch the product, cord or plug with wet or damp hands.
- Do not expose the product to direct sunlight, high temperatures, humidity, dust or corrosive substances.
- Never leave the product when it is turned on.
- When the product is in use, it should be kept under constant supervision. Children should always be supervised when using the product to ensure that they do not play with the product. The product is not a toy.
- The product may have sharp parts and must, therefore, be kept

out of reach of children.

- Only use the accessories that come with the product or that are recommended by the manufacturer.
- The product must not be used by people with reduced sensitivity, physical or mental disability, or people who are not able to operate the product unless they are supervised or instructed by a person responsible for their safety.

CORD AND PLUG

- Do not let the cord hang over the edge.
- Keep the cord and the product away from heat sources, hot objects and open flames.
- Unplug the power cord before cleaning and if the product is not in use. Do not pull the cord when removing the plug from the socket, rather grasp the plug itself.
- Make sure that the cord is fully extended.
- Check regularly that the cord and the plug are not damaged and do not use the product if this is the case, or if it has been dropped on the floor, dropped in water or damaged in another way.
- If the product or plug is damaged, the product must be inspected and, if necessary, repaired by an authorised repairer. Never try to repair the product yourself. Please, contact the store to see if there is a repair that falls under warranty. Tampering of the product will void the warranty.


RULES OF COMPLAINTS THE WARRANTY DOES NOT APPLY:

- If the above is not observed.
- If there has been unauthorised intervention of the product.
- If the product has been mishandled, subjected to rough treatment or some other form of damage.

PRODUCT DISPOSAL

Used product should not be disposed as household waste. According to legislation, the product should be disposed of

properly so that the materials can be recycled in an environmentally friendly manner. Further information is available from the responsible local authority or local disposal company. The product is equipped with the following logo:



SYMBOL EXPLANATION



Read the instructions for use



Do not bleach



Do not iron



Do not dry clean



Do not tumble dry



Do not inset pins



Do not use folded or rucked



Hand wash, maximum temp. 40 °C



Not to be used by very young children (0-3 years)

FITTED ELECTRIC BLANKETS

The appliance should not be used on an adjustable bed.

Place the blanket on mattress with the mains lead at the pillow end. Ensure the controller emerges from the top side of the blanket and that heating elements do not emerge under the pillow area.

Locate the elastic string at the corner of the bed so that the electric blanket fits snug around the mattress base. The electric blanket should now be securely fixed to the mattress smooth, out any rucks or folds in the blanket, then make the bed in your usual manner.

NEVER TURN ON THE BLANKET BEFORE IT IS COMPLETELY UNFOLDED. A FAILURE TO DO SO WILL RESULT IRREPARABLE PRODUCT DAMAGE. THE BLENKET WILL NEVER FEEL COMPLETELY WARM UNTIL YOU LIE ON IT. THE BLANKET’S HEAT LEVEL ADJUST TO PREVENT BURNS. DO NOT TUCK IN.

**USING THE BLANKET
TEMPERATURE SETTINGS**

Setting	Function
 button	Turn on or turn off
1	1 level, low heat level
2	2 level
3	3 level
4	4 level
5	5 level
6	6 level, high heat level

It takes approximately 15 minutes for the blanket to reach the desired temperature. Remember that a temperature that feels warm on the hand may be extremely hot on other part of the body.

You may notice a faint odour at the first time the blanket being heated. But be sure to air the room after the blanket has been heated for the first time.

The heat pad is equipped with an automatic cutout. This switches the unit off after 8 hours of operation. You can press the start button to switch the heat pad back on, 1 level is the default setting when you switch on each time.

**CLEANING & MAINTAINANCE
CLEANING**

The blanket can be hand-washed at a water temperature below 40 °C.

Do NOT iron the blanket.

Do NOT dry using a tumble dryer.

Do NOT dry the blanket in the sun.

Do NOT use an appliance such as a hair dryer to dry it.

Allow the blanket to dry naturally.

Do NOT use the blanket if it is damp or wet.

STORAGE

When not in use, allow it to cool down before folding, then gently fold the blanket and place back into the packing bag it arrived in.

Make sure the blanket is dry before folding and packing it away. The blanket should be hung in a ventilated location to dry naturally.

Do not use mothproofing agents on the blanket.

Do not crease the appliance by placing items on top of it during storage.

The blanket should be stored in a cool dry place.

TECHNICAL DATA

Article No. 11088814
220-240V~, 50/60Hz
100 Watt

PRODUCER

Epiq ApS
Krøyer Kielbergs Vej 3, 3. th
8660 Skanderborg, Denmark
www.epiq.dk

We cannot be held responsible for any printing errors.