

# salling



## INSTRUCTION MANUAL HEATING PAD

10958262

## INTRODUKTION

Mange tak fordi du har valgt et produkt fra Salling. Dermed har du erhvervet et kvalitetsprodukt som opfylder alle gældende krav til præstation og sikkerhedsstandarder i EU. For at sikre en korrekt behandling og en lang levetid anbefaler vi, at du overholder nedenstående anvisninger.

Du bedes læse vejledningen og især sikkerheds anvisningerne omhyggeligt igennem, inden du tager produktet i brug. Opbevar denne betjeningsvejledning, og overlad altid kun produktet til andre sammen med betjeningsvejledningen.

## GENERELLE SIKKERHEDSFORANSTALTNINGER

- Forkert brug af produktet kan medføre personskade og beskadige produktet.
- Anvend kun produktet til det, det er beregnet til. Producenten er ikke ansvarlig for skader, der opstår som følge af forkert brug eller håndtering.
- Anbring altid produktet på et tørt, plant og stabilt underlag på god afstand af bordkant eller lignende.
- Produktet er udelukkende beregnet til husholdningsbrug. Produktet må ikke anvendes til erhvervsbrug.
- Produktet må kun sluttes til 220-240V~, 50/60Hz.
- Produktets motordel/elektronik, ledning og stikket må ikke nedsænkes i vand, og der må ikke trænge vand i motordel/elektronik.
- Rør aldrig ved produktet, ledningen eller stikkontakten med våde eller fugtige hænder.
- Udsæt ikke produktet for direkte sollys, høje temperaturer, fugt, støv eller ætsende stoffer.
- Forlad aldrig produktet, når det er tændt.
- Når produktet er i brug, bør det holdes under konstant opsyn.
- Når produktet bruges skal børn der opholder sig i nærheden af

den altid holdes under opsyn.

- Børn må ikke lege med produktet.
- Produktet kan indeholde skarpe dele og bør derfor opbevares utilgængeligt for børn.
- Brug kun tilbehør, der følger med produktet eller er anbefalet af producenten.
- Produktet må ikke bruges af personer med nedsat følsomhed, fysiske eller mentale handicap, eller personer, som ikke er i stand til at betjene produktet, medmindre de overvåges eller instrueres i brugen af en person, som er ansvarlig for deres sikkerhed.

## **LEDNING OG STIK**

- Lad ikke ledningen hænge ud over bordkanten.
- Hold ledningen og produktet væk fra varmekilder, varme genstande og åben ild.
- Tag stikket ud af stikkontakten før rengøring, og hvis produktet ikke er i brug. Undlad at trække i ledningen, når du tager stikket ud af stikkontakten, men tag fat om selve stikket.
- Sørg for, at ledningen er rullet helt ud.
- Kontrollér jævnligt, om ledningen eller stikket er beskadiget, og brug ikke produktet, hvis dette er tilfældet, eller hvis det har været tabt på gulvet, tabt i vand eller er blevet beskadiget på en anden måde.
- Hvis produktet, ledningen eller stikket er beskadiget, skal produktet efterses og om nødvendigt repareres af en autoriseret reparatør. Forsøg aldrig at reparere produktet selv. Kontakt købsstedet, hvis der er tale om en reparation, der falder ind under reklamationsretten. Hvis der foretages uautoriserede indgreb i produktet, bortfalder reklamationsretten.

## **REKLAMATIONSRETEN GÆLDER IKKE:**

- Hvis ovennævnte ikke iagttages.
- Hvis der har været foretaget uautoriserede indgreb i produktet.
- Hvis produktet har været misligholdt, udsat for en voldsom behandling eller lidt anden form for overlast.

## **BORTSKAFFELSE AF PRODUKTET**

Brugte produkter må ikke smides i husholdningsaffaldet. Iht. lovforskrifterne skal det udtjente produkt bortskaffes på ordentlig vis. Derved genanvendes de brugbare materialer, og miljøet skånes. Nærmere informationer fås hos den ansvarlige kommunale myndighed eller det lokale bortskaffelsesfirma. Produktet er forsynet med følgende logo:



## SYMBOLFORKLARING

-  Må ikke bleges
-  Må ikke stryges
-  Må ikke renses
-  Må ikke tørretumbles
-  Indsæt ikke stifter
-  Må ikke bruges foldet eller ujævnt
-  Håndvaskes, maksimal temp.40 °C
-  Må ikke anvendes til småbørn i alderen 0-3 år

## ADVARSEL:

Denne varmepude skal håndteres forsigtigt, da dens varmetråde er tynde.

## STRØMFORSYNING

- Kontroller, at varmepuden er slukket, og at strømforsyningen er i overensstemmelse med den spænding, der er angivet på etiketten, inden du tilslutter varmepuden til strømforsyningen.
  - Hold netledningen og betjeningsenheden væk fra varme, fugt og væsker. Rør aldrig ved stikkontakten, når dine hænder er våde, eller hvis du står i vand.
  - Betjen kun varmepuden med den tilsvarende omskifterenhed.
  - Rør ikke ved en varmepude, der er faldet i vand. Træk i stedet stikket ud af stikkontakten med det samme.
  - Tag altid stikket ud af stikkontakten for at afbryde varmepuden. Hiv aldrig i kablet!
  - Bær, træk eller vend ikke varmepuden ved hjælp af netledningen.
  - Sørg for, at stikkontakten og stikket er let tilgængelige, så du hurtigt kan tage stikket ud af stikkontakten, hvis det er nødvendigt. Placer netledningen, så der ikke er risiko for at snuble over den.
- Kablet må ikke bøjes, snoes eller ligge i klemme.

## ENHED OG STYRING

1. Controller
2. Betjeningsdisplay
3. Kabel med stik
4. Varmepude
5. Tilslutning

## VED LEVERING

Kontroller først og fremmest, at enheden er fuldstændig og ikke er beskadiget på nogen måde. I tilfælde af tvivl skal du ikke bruge den, men i stedet kontakte din leverandør eller dit servicecenter.

## FØLGENDE DELE ER INKLUDERET:

- 1 varmegude
- 1 Instruktionsmanual Hvis du opdager transportskader under udpakningen, bedes du straks kontakte din leverandør.

## BRUG

Du kan bruge varmeguden til at varme og give afslapning til alle dele af kroppen. Varmeguden når en behagelig temperatur inden for få minutter, efter den bliver tændt. Temperaturen kan justeres efter behov.

## BETJENING

Sæt stikket i stikkontakten og tænd varmeguden. Når puden er tændt, vises reguleringsniveauet på betjeningsdisplayet. Jo højere reguleringsniveauet er, desto højere er temperaturen.

For at slukke for puden, trykke på  knappen. Hvis betjeningsdisplayet slukker, er enheden slukket. Varmeguden slukker automatisk efter ca. 90 minutters kontinuerlig brug. Tag stikket ud af stikkontakten, når du er færdig med at bruge den.

## TEMPERATURTRIN

| Indstilling                                                                            | Funktion                   |
|----------------------------------------------------------------------------------------|----------------------------|
|  knap | Tænd eller sluk            |
| 1                                                                                      | 1 niveau, lavt varmeniveau |
| 2                                                                                      | 2 niveau                   |
| 3                                                                                      | 3 niveau                   |
| 4                                                                                      | 4 niveau                   |
| 5                                                                                      | 5 niveau                   |
| 6                                                                                      | 6 niveau, højt varmeniveau |

## AUTOMATISK SLUKKEFUNKTION

Underlagets varmefunktion slukker automatisk efter 90 minutters. Du kan trykke på startknappen for at tænde for varmeguden igen, 1 niveau er standardindstillingen, når du tænder hver gang. Du kan derefter vælge det ønskede temperaturtrin.

## RENGØRING OG VEDLIGEHOLDELSE

- Træk stikket ud af stikkontakten, og lad puden køle af i mindst ti minutter, inden du rengør den.
- Varmeelementet er udstyret med et aftageligt kabel. Tag stikket fra og fjern kablet fra varmepuden.
- Du kan vaske varmepuden forsigtigt i hånden. Den bedste måde at gøre dette på er at lægge varmepuden i et blød i lunkent vand og lidt mildt rengøringsmiddel og derefter forsigtigt presse det ud.
- For at tørre, stræk puden ud på en plan overflade.
- Skyl varmepuden flere gange for at fjerne alle rester af rengøringsmiddel.
- Når du ikke bruger den, skal puden opbevares på et rent og tørt sted, udlagt fladt, uden at der er noget, der dækker den eller står oven på den.
- Lad puden afkøle, inden den foldes sammen.
- Lav ikke rynker i puden ved at sætte andre ting ovenpå den under opbevaring.
- Tjek puden jævnligt for eventuelle tegn på slitage eller beskadigelse. Hvis der er sådanne tegn, eller hvis puden er blevet misbrugt, skal den returneres til leverandøren inden yderligere brug.
- Anvend kun puden, når den er helt tør.

### TEKNISKE DATA

Artikelnr. 10958262  
220-240V~, 50/60Hz  
100 Watt

### PRODUCENT

Epiq ApS  
Krøyer Kielbergs Vej 3, 3. th  
8660 Skanderborg, Danmark  
[www.epiq.dk](http://www.epiq.dk)

Vi tager forbehold for trykfejl.

## INTRODUCTION

Thank you for choosing a product from Salling. You have acquired a quality product which meets all applicable performance and safety standards in the EU. In order to ensure proper treatment and a long product life, we recommend that you comply with the instructions below.

Please read the manual and especially the safety instructions carefully before using the product. Keep this manual and provide it for referral along with the product when others are using it.

## GENERAL SAFETY INSTRUCTIONS

- Improper use of the product can cause personal injury and damage.
- Only use the product for what it is intended. The manufacturer is not liable for damages arising from improper use or handling.
- Always place the product on a dry, flat and stable surface well away from table edge or similar.
- The product is intended for household use only. The product is not for professional use.
- The product may only be connected to 220-240V~, 50/60Hz.
- The product engine/electronics, cord or plug cannot be submerged in water, and no water may get in contact with the engine/electronics.
- Never touch the product, cord or plug with wet or damp hands.
- Do not expose the product to direct sunlight, high temperatures, humidity, dust or corrosive substances.
- Never leave the product when it is turned on.
- When the product is in use, it should be kept under constant supervision. Children should always be supervised when using the product to ensure that they do not play with the product. The product is not a toy.
- The product may have sharp parts and must, therefore, be kept

out of reach of children.

- Only use the accessories that come with the product or that are recommended by the manufacturer.
- The product must not be used by people with reduced sensitivity, physical or mental disability, or people who are not able to operate the product unless they are supervised or instructed by a person responsible for their safety.

## **CORD AND PLUG**

- Do not let the cord hang over the edge.
- Keep the cord and the product away from heat sources, hot objects and open flames.
- Unplug the power cord before cleaning and if the product is not in use. Do not pull the cord when removing the plug from the socket, rather grasp the plug itself.
- Make sure that the cord is fully extended.
- Check regularly that the cord and the plug are not damaged and do not use the product if this is the case, or if it has been dropped on the floor, dropped in water or damaged in another way.
- If the product or plug is damaged, the product must be inspected and, if necessary, repaired by an authorised repairer. Never try to repair the product yourself. Please, contact the store to see if there is a repair that falls under warranty. Tampering of the product will void the warranty.

## **RULES OF COMPLAINTS THE WARRANTY DOES NOT APPLY:**

- If the above is not observed.
- If there has been unauthorised intervention of the product.
- If the product has been mishandled, subjected to rough treatment or some other form of damage.

## **PRODUCT DISPOSAL**

Used product should not be disposed as household waste. According to legislation, the product should be disposed of

properly so that the materials can be recycled in an environmentally friendly manner. Further information is available from the responsible local authority or local disposal company. The product is equipped with the following logo:



## SYMBOL EXPLANATIONS



Do not bleach



Do not iron



Do not dry clean



Do not tumble dry



Do not insert pins



Do not use folded or rucked



Hand wash, maximum temp. 40 °C



Can't not be used with 0-3 years old infants and young children

## WARNING:

This heating pad should be handled carefully, as its heating threads are thin.

## POWER SUPPLY

- Before connecting the heat pad to the power supply, please check that it is switched off and that the mains voltage of your power supply corresponds to the voltage listed on the label.
- Keep the mains cable and control unit away from heat, humidity, and liquids. Never touch the mains plug when your hands are wet or when you are standing in water.
- Only operate the heating pad with the corresponding switch unit.
- Do not attempt to touch a heating pad that has fallen into the water. Pull the plug out of the socket immediately.
- To disconnect the heat pad, always pull the mains plug out of the mains socket. Never pull on the cable!
- Do not carry, pull, or twist the heating pad using the main cable.
- Make sure that the power socket and plug are easily accessible, so you can unplug the mains quickly if necessary. Lay the power cord so that there is no danger of tripping over it.

The cable must not be bent, trapped, or twisted.

## DEVICE AND CONTROLS

1. Control unit with the sliding switch
2. Operating control display
3. Cable with plug
4. Heating pad

5. Connection

SCOPE OF SUPPLY

Please check first that the device is complete and is not damaged in any way. In case of doubt, do not use it, and contact your supplier or your service center.

THE FOLLOWING PARTS ARE INCLUDED:

- 1 Heat pad
- 1 Instruction manual If you notice any transport damage during unpacking, please contact your supplier without delay.

USE

You can use the heat pad to gently heat and relax any part of the body. The heat pad reaches a pleasant temperature within a few minutes of switching on. The temperature can be adjusted as required.

OPERATION

Insert the mains plug into the socket and switch on the heat pad. When the appliance is switched on, the regulating level appears on the operating control display. The higher the regulating level, the higher the temperature. To switch off the unit, press the  button If the operating control display goes out, the The device is switched off. The heat pad will switch off automatically after approx. 90 minutes of continuous use. Unplug the unit from the main outlet once you have finished using it.

TEMPERATURE SETTINGS

| Setting                                                                                  | Function                 |
|------------------------------------------------------------------------------------------|--------------------------|
|  button | Turn on or turn off      |
| 1                                                                                        | 1 level, low heat level  |
| 2                                                                                        | 2 level                  |
| 3                                                                                        | 3 level                  |
| 4                                                                                        | 4 level                  |
| 5                                                                                        | 5 level                  |
| 6                                                                                        | 6 level, high heat level |

AUTOMATIC CUTOUT

The heating pad is equipped with an automatic cutout. This switches the unit off after 90 minutes of operation. You can press the start button to switch the heat pad back on, 1 level is the default setting when you switch on each time.

## CLEANING AND MAINTENANCE

- Before cleaning the pad, unplug it from the mains outlet and let it cool down for at least ten minutes.
- The heating pad is equipped with a detachable cable. Disconnect the plug and remove the cable from the heating pad.
- You may wash the heating pad gently by hand. The best way to do this is to put the heating pad in a bath with lukewarm water and some mild detergent and then gently squeeze it out.
- To dry, stretch the pad out on a flat surface.
- Rinse the heating pad several times to remove all the detergent.
- When not in use, store the unit in a clean and dry place, laid out flat with nothing covering or resting on top of it.
- When storing the appliance, allow it to cool down before folding.
- Do not crease the heating pad by placing items on top of it during storage.
- Examine the appliance frequently for signs of wear or damage. If there are such signs or if the appliance has been misused, return it to the supplier prior to any further use.
- Only use the appliance once it is completely dry.

### TECHNICAL DATA

Article No. 10958262  
220-240V~, 50/60Hz  
100 Watt

### PRODUCER

Epiq ApS  
Krøyer Kielbergs Vej 3, 3. th  
8660 Skanderborg, Denmark  
[www.epiq.dk](http://www.epiq.dk)

We cannot be held responsible for any printing errors.