

BRUGSANVISNING / INSTRUCTION MANUAL

VAFFELJERN / WAFFLE MAKER / 80001872



INTRODUKTION

Tillykke med dit nye produkt. Dermed har du erhvervet et kvalitetsprodukt som opfylder alle gældende krav til præstation og sikkerhedsstandarder i EU. For at sikre en korrekt behandling og en lang levetid anbefaler vi, at du overholder nedenstående anvisninger.

Du bedes læse vejledningen og især sikkerheds anvisningerne omhyggeligt igennem, inden du tager produktet i brug. Opbevar denne betjeningsvejledning, og overlad altid kun produktet til andre sammen med betjeningsvejledningen.

GENERELLE SIKKERHEDSFORANSTALTNINGER

- Forkert brug af produktet kan medføre personskade og beskadige produktet.
- Anvend kun produktet til det, det er beregnet til. Producenten er ikke ansvarlig for skader, der opstår som følge af forkert brug eller håndtering.
- Anbring altid produktet på et tørt, plant og stabilt underlag på god afstand af bordkant eller lignende.
- Produktet er udelukkende beregnet til husholdningsbrug. Produktet må ikke anvendes til erhvervsbrug.
- Produktet må kun sluttes til 220-240V~, 50/60Hz.
- Produktets motordel/elektronik, ledning og stikket må ikke nedsænkes i vand, og der må ikke trænge vand i motordel/elektronik.
- Rør aldrig ved produktet, ledningen eller stikkontakten med våde eller fugtige hænder.
- Udsæt ikke produktet for direkte sollys, høje temperaturer, fugt, støv eller ætsende stoffer.
- Forlad aldrig produktet, når det er tændt.
- Når produktet er i brug, bør det holdes under konstant opsyn.
- Når produktet bruges skal børn der opholder sig i nærheden af

den altid holdes under opsyn.

- Børn må ikke lege med produktet.
- Produktet kan indeholde skarpe dele og bør derfor opbevares utilgængeligt for børn.
- Brug kun tilbehør, der følger med produktet eller er anbefalet af producenten.
- Produktet må ikke bruges af personer med nedsat følsomhed, fysiske eller mentale handicap, eller personer, som ikke er i stand til at betjene produktet, medmindre de overvåges eller instrueres i brugen af en person, som er ansvarlig for deres sikkerhed.

LEDNING OG STIK

- Lad ikke ledningen hænge ud over bordkanten.
- Hold ledningen og produktet væk fra varmekilder, varme genstande og åben ild.
- Tag stikket ud af stikkontakten før rengøring, og hvis produktet ikke er i brug. Undlad at trække i ledningen, når du tager stikket ud af stikkontakten, men tag fat om selve stikket.
- Sørg for, at ledningen er rullet helt ud.
- Kontrollér jævnligt, om ledningen eller stikket er beskadiget, og brug ikke produktet, hvis dette er tilfældet, eller hvis det har været tabt på gulvet, tabt i vand eller er blevet beskadiget på en anden måde.
- Hvis produktet, ledningen eller stikket er beskadiget, skal produktet efterses og om nødvendigt repareres af en autoriseret reparatør. Forsøg aldrig at reparere produktet selv. Kontakt købsstedet, hvis der er tale om en reparation, der falder ind under reklamationsretten. Hvis der foretages uautoriserede indgreb i produktet, bortfalder reklamationsretten.

REKLAMATIONSRETEN GÆLDER IKKE:

- Hvis ovennævnte ikke iagttages.
- Hvis der har været foretaget uautoriserede indgreb i produktet.
- Hvis produktet har været misligholdt, udsat for en voldsom behandling eller lidt anden form for overlast.

BORTSKAFFELSE AF PRODUKTET

Brugte produkter må ikke smides i husholdningsaffaldet. Iht. lovforskrifterne skal det udtjente produkt bortskaffes på ordentlig vis. Derved genanvendes de brugbare materialer, og miljøet skånes. Nærmere informationer fås hos den ansvarlige kommunale myndighed eller det lokale bortskaffelsesfirma. Produktet er forsynet med følgende logo:



DELE



FØR FØRSTE BRUG

Fjern eventuelle reklame- og emballagematerialer, før du bruger apparatet første gang. Kontrollér, at varmepladerne er rene og uden støv. Tør eventuelt varmepladerne af med en fugtig klud. Du får det bedste resultat ved at hælde en teskefuld planteolie på slip-let-belægningen på varmepladerne. Spred olien jævnt med et stykke sugende køkkenrulle, og tør derefter eventuel overskydende olie af.

BRUG DIT VAFFELJERN

- Vaffeljernet kan udsende en let røg eller lugt, når du bruger det første gang. Dette er normalt for mange apparater, der afgiver varme, og påvirker ikke apparatets sikkerhed.
- Sæt stikket i en stikkontakt. Kontrollampen for strøm tænder og viser, at vaffeljernet er begyndt at forvarme.
- Lad vaffeljernet forvarme, indtil kontrollampen for strøm slukker. Det angiver, at varmepladerne har nået den korrekte temperatur.
- Sprøjt varmepladerne med lidt madolie før brugen. Det gør det nemmere at fjerne vafferne, når de er færdige.
- Spred dejen ud over vaffelhullerne efter opskriften. Brug en kande, en ske eller en sprøjtepose af stof.

Bemærk: Brug ikke engangssprøjteposer af plastik, da de kan smelte, hvis de kommer i kontakt med de varme varmeplader.

- Luk låget. Luk ikke låget hurtigt da det kan medføre, at dejen løber over.
- Bag vafferne i ca. 3-5 minutter, eller indtil de er gyldenbrune.
- Brug altid en spatel af plastik eller træ, når du fjerner vafferne. Brug aldrig skarpe genstande eller metalkøkkengrej, da de kan beskadige slip-let-belægningen på varmepladerne.

RENGØRING OG PLEJE

- Sluk altid for strømmen, og træk stikket til apparatet ud af stikkontakten før rengøring.
- Varmepladerne har en slip-let-belægning og kræver derfor kun lidt rengøring. Tør dem

blot af med en fugtig klud.

- Læg ikke vaffeljernet i vand eller andre væsker.
- Brug ikke skuresvampe, skurepulver eller skrappe rensemidler.
- Læg ikke apparatet i opvaskemaskinen.
- Smør lidt olie på varmepladerne inden næste brug. Så slipper vafflerne lettere.

OPBEVARING

- Træk altid stikket til vaffeljernet ud af stikkontakten før opbevaring.
- Sørg for, at vaffelapparatet er helt afkølet og tørt før opbevaringen.
- Vaffeljernet kan opbevares i en lodret stilling og derved spare plads i køkkenet.

TEKNISKE DATA

Artikelnr. 80001872
220-240V~, 50/60Hz
1000 Watt

PRODUCENT

Epiq ApS
Krøyer Kielbergs Vej 3, 3. th
8660 Skanderborg, Danmark
www.epiq.dk

Vi tager forbehold for trykfejl.

INTRODUCTION

Congratulations on your new product. You have acquired a quality product which meets all applicable performance and safety standards in the EU. In order to ensure proper treatment and a long product life, we recommend that you comply with the instructions below.

Please read the manual and especially the safety instructions carefully before using the product. Keep this manual and provide it for referral along with the product when others are using it.

GENERAL SAFETY INSTRUCTIONS

- Improper use of the product can cause personal injury and damage.
- Only use the product for what it is intended. The manufacturer is not liable for damages arising from improper use or handling.
- Always place the product on a dry, flat and stable surface well away from table edge or similar.
- The product is intended for household use only. The product is not for professional use.
- The product may only be connected to 220-240V~, 50/60Hz.
- The product engine/electronics, cord or plug cannot be submerged in water, and no water may get in contact with the engine/electronics.
- Never touch the product, cord or plug with wet or damp hands.
- Do not expose the product to direct sunlight, high temperatures, humidity, dust or corrosive substances.
- Never leave the product when it is turned on.
- When the product is in use, it should be kept under constant supervision. Children should always be supervised when using the product to ensure that they do not play with the product. The product is not a toy.
- The product may have sharp parts and must, therefore, be kept

out of reach of children.

- Only use the accessories that come with the product or that are recommended by the manufacturer.
- The product must not be used by people with reduced sensitivity, physical or mental disability, or people who are not able to operate the product unless they are supervised or instructed by a person responsible for their safety.

CORD AND PLUG

- Do not let the cord hang over the edge.
- Keep the cord and the product away from heat sources, hot objects and open flames.
- Unplug the power cord before cleaning and if the product is not in use. Do not pull the cord when removing the plug from the socket, rather grasp the plug itself.
- Make sure that the cord is fully extended.
- Check regularly that the cord and the plug are not damaged and do not use the product if this is the case, or if it has been dropped on the floor, dropped in water or damaged in another way.
- If the product or plug is damaged, the product must be inspected and, if necessary, repaired by an authorised repairer. Never try to repair the product yourself. Please, contact the store to see if there is a repair that falls under warranty. Tampering of the product will void the warranty.

RULES OF COMPLAINTS THE WARRANTY DOES NOT APPLY:

- If the above is not observed.
- If there has been unauthorised intervention of the product.
- If the product has been mishandled, subjected to rough treatment or some other form of damage.

PRODUCT DISPOSAL

Used product should not be disposed as household waste. According to legislation, the product should be disposed of

properly so that the materials can be recycled in an environmentally friendly manner. Further information is available from the responsible local authority or local disposal company. The product is equipped with the following logo:



PARTS



BEFORE FIRST USE

Before using the appliance for the first time, remove any promotional and packaging materials. Check that the cooking plates are clean and free from dust. If necessary, wipe them with a damp cloth. For best results, pour a teaspoon of vegetable oil onto the non-stick cooking plates. Spread it evenly using an absorbent kitchen towel, then wipe off any excess oil.

USING YOUR WAFFLE MAKER

- When using your waffle maker for the first time, it may emit a slight smoke or odor. This is normal for many heating appliances and does not affect the safety of the unit.
- Insert the power plug into a power outlet. The power indicator will turn on, indicating that the waffle maker has begun preheating.
- Allow the waffle maker to preheat until the ready indicator turns off. This signals that the cooking plates have reached the correct temperature.
- For best results, lightly spray the cooking plates with cooking oil before use. This will make it easier to remove the waffles after cooking.
- Pour the mixture into the pan cavities according to the recipe, using a jug, spoon, or fabric piping bag.

Note: Do not use disposable plastic piping bags, as they may melt if they come into contact with the hot cooking plates.

- Gently close the lid. Do not slam it shut, as this may cause the batter to overflow.
- Allow the waffles to cook for approximately 3–5 minutes or until golden brown.
- To remove the waffles, always use a plastic or wooden spatula. Never use sharp or metal utensils, as they can damage the non-stick coating on the cooking plates.

CLEANING AND CARE

- Always turn off the power and unplug the appliance before cleaning.
- The cooking plates have a non-stick coating, so minimal cleaning is required. Simply wipe them with a damp cloth.

- Do not immerse the waffle maker in water or any other liquid.
- Do not use abrasive scouring pads, powders, or harsh cleaners.
- Do not place the appliance in the dishwasher.
- Lightly grease the cooking plates before the next use to ensure easy removal of the waffles.

STORAGE

- Always unplug the waffle maker before storing it.
- Ensure the waffle maker is completely cool and dry before storage.
- To save space in your kitchen, the waffle maker can be stored in a vertical position.

TECHNICAL DATA

Article No. 80001872
220-240V~, 50/60Hz
1000 Watt

PRODUCER

Epiq ApS
Krøyer Kielbergs Vej 3, 3. th
8660 Skanderborg, Denmark
www.epiq.dk

We cannot be held responsible for any printing errors.