

salling



INSTRUCTION MANUAL KETTLE

10482901

INTRODUKTION

Mange tak fordi du har valgt et produkt fra Salling. Dermed har du erhvervet et kvalitetsprodukt som opfylder alle gældende krav til præstation og sikkerhedsstandarder i EU. For at sikre en korrekt behandling og en lang levetid anbefaler vi, at du overholder nedenstående anvisninger.

Du bedes læse vejledningen og især sikkerheds anvisningerne omhyggeligt igennem, inden du tager produktet i brug. Opbevar denne betjeningsvejledning, og overlad altid kun produktet til andre sammen med betjeningsvejledningen.

GENERELLE SIKKERHEDSFORANSTALTNINGER

- Forkert brug af produktet kan medføre personskade og beskadige produktet.
- Anvend kun produktet til det, det er beregnet til. Producenten er ikke ansvarlig for skader, der opstår som følge af forkert brug eller håndtering.
- Anbring altid produktet på et tørt, plant og stabilt underlag på god afstand af bordkant eller lignende.
- Produktet er udelukkende beregnet til husholdningsbrug. Produktet må ikke anvendes til erhvervsbrug.
- Produktet må kun sluttes til 220-240V~, 50-60Hz.
- Produktets motordel/elektronik, ledning og stikket må ikke nedsænkes i vand, og der må ikke trænge vand i motordel/elektronik.
- Rør aldrig ved produktet, ledningen eller stikkontakten med våde eller fugtige hænder.
- Udsæt ikke produktet for direkte sollys, høje temperaturer, fugt, støv eller ætsende stoffer.
- Forlad aldrig produktet, når det er tændt.
- Når produktet er i brug, bør det holdes under konstant opsyn.
- Når produktet bruges skal børn der opholder sig i nærheden af

den altid holdes under opsyn.

- Børn må ikke lege med produktet.
- Produktet kan indeholde skarpe dele og bør derfor opbevares utilgængeligt for børn.
- Brug kun tilbehør, der følger med produktet eller er anbefalet af producenten.
- Produktet må kun anvendes sammen med medfølgende base.
- Undgå at spilde vand på basen.
- Overstigning af max vandstand kan forårsage udskydning af kogende vand.
- Fjern ikke låget mens vandet koger.
- På modeller med aftageligt låg, skal man sørge for at låget sidder korrekt så evt. damp ledes væk fra håndtaget.
- Varmelegemet kan være meget varmt efter brug grundet restvarme.
- Produktet må bruges af børn på 8 år eller derover og personer med reducerede fysiske, sensoriske eller mentale evner, eller som mangler erfaring og viden, hvis de er under opsyn eller har modtaget instruktion i sikker brug af produktet og forstår de involverede farer.
- Hold produktet og ledningen uden for rækkevidden af børn under 8 år.
- Rengøring og vedligeholdelse må ikke udføres af børn med mindre de er ældre end 8 år og under opsyn.

LEDNING OG STIK

- Lad ikke ledningen hænge ud over bordkanten.
- Hold ledningen og produktet væk fra varmekilder, varme genstande og åben ild.
- Tag stikket ud af stikkontakten før rengøring, og hvis produktet ikke er i brug. Undlad at trække i ledningen, når du tager stikket ud af stikkontakten, men tag fat om selve stikket.
- Sørg for, at ledningen er rullet helt ud.
- Kontrollér jævnligt, om ledningen eller stikket er beskadiget, og brug ikke produktet, hvis dette er tilfældet, eller hvis det har været

tabt på gulvet, tabt i vand eller er blevet beskadiget på en anden måde.

- Hvis produktet, ledningen eller stikket er beskadiget, skal produktet efterses og om nødvendigt repareres af en autoriseret reparatør. Forsøg aldrig at reparere produktet selv. Kontakt købsstedet, hvis der er tale om en reparation, der falder ind under reklamationsretten. Hvis der foretages uautoriserede indgreb i produktet, bortfalder reklamationsretten.

REKLAMATIONSRETEN GÆLDER IKKE:

- Hvis ovennævnte ikke iagttages.
- Hvis der har været foretaget uautoriserede indgreb i produktet.
- Hvis produktet har været misligholdt, udsat for en voldsom behandling eller lidt anden form for overlast.

BORTSKAFFELSE AF PRODUKTET

Brugte produkter må ikke smides i husholdningsaffaldet. Iht. lovforskrifterne skal det udtjente produkt bortskaffes på ordentlig vis. Derved genanvendes de brugbare materialer, og miljøet skånes. Nærmere informationer fås hos den ansvarlige kommunale myndighed eller det lokale bortskaffelsesfirma. Produktet er forsynet med følgende logo:



KEND DIN KEDEL



FØR ELKEDLEN BRUGES FØRSTE GANG

Træk i lågets udløserknop [1] for at åbne låget, og fyld elkedlen op til "MAX" med koldt vand uden rengøringsmiddel.

Sæt elkedlen på sokkel [5].

Sæt stikket i stikkontakten, og tryk på omskifter [4].

Når kogeprocessen er færdig, skal du hælde vandet ud, og gentage processen to til tre gange.

BETJENINGSVEJLEDNING

1. Træk i lågets udløserknop [1], og fyld kedlen med koldt vand.

TIP: Spar strøm - Kog kun den mængde vand, du skal bruge.

Bemærk! Sørg for, at vandstanden ikke er lavere end min. mærket og ikke overstiger MAX-mærket inde i kedlen.

2. Sæt kedlen på sokkel [5].
3. Sæt stikket i stikkontakten, og tryk på tænd/sluk-knappen [4]. Kontrollampen [6] tændes.
4. Elkedlen slår automatisk fra når vandet koger. Kontrollampen [6] slukkes.
5. Træk stikket ud af stikkontakten.

For at afbryde kogningen skal du sørge for, at omskifter er i positionen "O" [OFF], før du tager elkedlen af soklen.

Der kan sidde dråber af vand under elkedlen, hvilket er helt normalt - det skyldes bare kondensering.

Bemærk: Tøm elkedlen hver gang efter brug.

AFKALKNING

Jævnlig afkalkning af det flade element forbedrer elkedlens ydelse. Hvis kedlen ikke afkalkes jævnligt, kan ophobningen af kalk resultere i følgende:

- Kedlen kan være længere om at koge.
- Det flade element kan blive beskadiget.

Bemærk: Manglende afkalkning af kedlen kan medføre, at garantien bortfalder.

Når kalk ophobes på varmeelementet:

- Køb et egnet afkalkningsmiddel i et supermarked, og afkalk elkedlen i henhold til anvisningerne på afkalkningsmidlets pakning.
- Efter afkalkningen skal du koge med frisk vand flere gange og hælde vandet ud.
- Rens elkedlen helt for afkalkningsmiddel - det kan beskadige delene.

Visse steder er vandet meget kalkholdigt. Kalken gør det kogte vand uklart og kan give aflejringer på indersiden af elkedlen. Det er normalt, men kan forebygges ved jævnlig rengøring.

Du kan alternativt fylde kedlen med filtreret vand for at mindske ophobningen af kalk.

PLEJE OG RENGØRING

Før du gør elkedlen ren, skal du trække den ud af stikkontakten og lade elkedlen køle af.

Udvendige flader og sokkel: Tør af med en fugtig klud, og lad tørre.

Brug aldrig kraftigt slibende rengøringsmidler.

Rengør aldrig med ståluldssvampe.

TEKNISKE DATA

Artikelnr. 10482901
220-240V~, 50/60Hz
1000 Watt
0,7 liter

PRODUCENT

Epiq ApS
Krøyer Kielbergs Vej 3, 3. th
8660 Skanderborg, Danmark
www.epiq.dk

Vi tager forbehold for trykfejl.

INTRODUCTION

Thank you for choosing a product from Salling. You have acquired a quality product which meets all applicable performance and safety standards in the EU. In order to ensure proper treatment and a long product life, we recommend that you comply with the instructions below.

Please read the manual and especially the safety instructions carefully before using the product. Keep this manual and provide it for referral along with the product when others are using it.

GENERAL SAFETY INSTRUCTIONS

- Improper use of the product can cause personal injury and damage.
- Only use the product for what it is intended. The manufacturer is not liable for damages arising from improper use or handling.
- Always place the product on a dry, flat and stable surface well away from table edge or similar.
- The product is intended for household use only. The product is not for professional use.
- The product may only be connected to 220-240V~, 50-60Hz.
- The product engine/electronics, cord or plug cannot be submerged in water, and no water may get in contact with the engine/electronics.
- Never touch the product, cord or plug with wet or damp hands.
- Do not expose the product to direct sunlight, high temperatures, humidity, dust or corrosive substances.
- Never leave the product when it is turned on.
- When the product is in use, it should be kept under constant supervision. Children should always be supervised when using the product to ensure that they do not play with the product. The product is not a toy.
- The product may have sharp parts and must, therefore, be kept

out of reach of children.

- Only use the accessories that come with the product or that are recommended by the manufacturer.
- The product may only be used with the supplied base.
- Avoid spilling water on the base.
- Exceeding the maximum water level may cause boiling water to be ejected.
- Do not remove the lid while the water is boiling.
- On models with a removable lid, make sure that the lid fits correctly so that any steam is directed away from the handle.
- The heating element can be very hot after use due to residual heat.
- This product can be used by children aged from 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the product in a safe way and understand the hazards involved.
- Keep the product and its cord out of reach of children less than 8 years of age.
- Cleaning and user maintenance shall not be made by children without supervision.

CORD AND PLUG

- Do not let the cord hang over the edge.
- Keep the cord and the product away from heat sources, hot objects and open flames.
- Unplug the power cord before cleaning and if the product is not in use. Do not pull the cord when removing the plug from the socket, rather grasp the plug itself.
- Make sure that the cord is fully extended.
- Check regularly that the cord and the plug are not damaged and do not use the product if this is the case, or if it has been dropped on the floor, dropped in water or damaged in another way.
- If the product or plug is damaged, the product must be

inspected and, if necessary, repaired by an authorised repairer. Never try to repair the product yourself. Please, contact the store to see if there is a repair that falls under warranty. Tampering of the product will void the warranty.

RULES OF COMPLAINTS THE WARRANTY DOES NOT APPLY:

- If the above is not observed.
- If there has been unauthorised intervention of the product.
- If the product has been mishandled, subjected to rough treatment or some other form of damage.

PRODUCT DISPOSAL

Used product should not be disposed as household waste. According to legislation, the product should be disposed of properly so that the materials can be recycled in an environmentally friendly manner. Further information is available from the responsible local authority or local disposal company. The product is equipped with the following logo:



KNOW YOUR KETTLE



BEFORE THE FIRST USE

Pull the lid lever [1] to open the lid and fill to “MAX” with cold water without detergent. Place the kettle on the base [5].

Plug in and press the switch [4].

Once the boiling process is finished, discard the water and repeat 2 to 3 times.

OPERATING INSTRUCTIONS

1. Pull the lid lever [1] and fill the kettle with cold water.

HINT: Save energy – Do not boil more water than you need.

Attention! Make sure the water level is not lower than the min mark and does not exceed the MAX indication inside the kettle.

2. Place the kettle on the base [5].
3. Plug in and press the switch [4]. The light indicator [6] will turn on.
4. Your kettle will boil and switch off automatically and the light indicator [6] will turn off.
5. Unplug the power cord.

To interrupt the boiling, ensure that the switch is in the “O” [OFF] position before removing the kettle from the power base.

If you find drops of water under your kettle, don't worry – it is just condensation.

Note: Empty the kettle after each use.

DESCALING

Regular descaling of the flat element will improve the performance of your kettle. If the kettle is not descaled regularly the buildup of limescale may result in the following:

- The kettle may take longer to boil.
- The flat element may be damaged.

Please note: Not descaling your kettle may invalidate your guarantee.

When lime scale starts to build up on the heating element:

- Buy a suitable descaler from a supermarket and descale your kettle following the instructions mentioned on the descaler packaging.
- After descaling, boil with fresh water several times and discard.
- Clean any descaler off the kettle – it can damage the parts.

Some regions have chalky water. This makes boiled water look cloudy and leaves deposit on the side of the kettle. This is normal but can be removed with regular cleaning.

Alternatively, to reduce limescale build up, use filtered water to fill your kettle.

CARE AND CLEANING

Before cleaning, unplug your kettle and let it cool down.

The outside and power base: Wipe with a damp cloth, then dry.

Never use highly corrosive or abstractive cleaning agents.

Never use metal scouring pads for cleaning.

TECHNICAL DATA

Article No. 10482901

220-240V~, 50/60Hz

1000 Watt

0.7 liter

PRODUCER

Epiq ApS

Krøyer Kielbergs Vej 3, 3. th

8660 Skanderborg, Denmark

www.epiq.dk

We cannot be held responsible for any printing errors.