KINETIC BODY SCALE
Size: 90x100 mm
Manual

Inkluderer

- Kinetisk badevægt

ADVARSEL/sikkerhedsforanstaltninger

- Badevægten bør kun placeres på et fast, jævnt underlag.
- Træd ikke op på vægten med våde fødder, da den ikke er skridsikker.
- Rengøring og vedligeholdelse af produktet må kun udføres af voksne.
- Produktet må ikke sænkes ned i vand eller andre væsker.
- Opbevar produktet på et tørt og mørkt sted.
- Ved tegn på skade på produktet, stop da omgående al brug.
- Forsøg ikke selv at reparere produktet.

Specifikationer

- Størrelse: 30 x 30 x 3 cm
- LCD-display
- Automatisk slukning (45 sek. +/- 5 sek.)
- Maks. belastning: 180 kg
- Batterifri, kinetisk badevægt
- Skift mellem kg, lb og st

Kinetisk funktion

- Badevægten er batterifri og bruger kinetisk energi for at tænde. Træd blot op på vægten for at generere energi og tænde vægten.

Anvendelse

- Træd direkte op på vægten. Træd ikke på displayet.
- Stå stille og vent et par sekunder.
- Din aktuelle vægt vises i displayet.
- Ved overbelastning vises fejlkoden *ERR* i displayet.
- Vægten slukker automatisk efter omkring 45 sek.
- Man kan foretage en ny måling ved at vente på at vægten har målt første gang (når displayet viser konstant den første vægt målt efter man er trådt af) eller vente på at vægten har slukket og så derefter træd op på vægten igen.

Skift måleenhed

- Skift måleenhed ved at trykke på knappen under vægten: kg, lbs og stone.

Vedligeholdelse/rengøring

- Tør badevægten over med en hårdt opvredet klud

Elektrisk og elektronisk udstyr (EEE) indeholder materialer, komponenter og stoffer, der kan være farlige og skadelige for menneskers sundhed og for miljøet, når affaldet af elektrisk og elektronisk udstyr (WEEE) ikke bortskaffes korrekt.

Produkter, der er mærket med nedenstående "overkrydsede skraldespand", er elektrisk og elektronisk udstyr. Den krydsede skraldespand symboliserer, at affald af elektrisk og elektronisk udstyr ikke må bortskaffes sammen med usorteret husholdningsaffald, men skal indsamles særskilt.

Til dette formål har alle kommuner etableret indsamlingsordninger, hvor affald af elektrisk og elektronisk udstyr gratis kan afleveres af borgerne på genbrugsstationer eller andre indsamlingssteder eller hentes direkte fra husholdningerne. Nærmere information skal indhentes hos kommunens tekniske forvaltning.

PO nr.: 109190
Vare nr.: 11335847

I tilfælde af problemer eller spørgsmål til produktet, kontakt da venligst producenten: Salling Group, Rosbjergvej 33, DK-8220, sallinggroup.com

Gem venligst manualen til fremtidig brug.

IP44 CE



KINETISK BADEVÆGT
MANUAL

Læs venligst manualen grundigt inden brug.

Includes

- Kinetic bathroom scale

WARNING/Safety precautions

- The bathroom scale should only be placed on a firm, even surface.
- Do not step on the scale with wet feet, as it is not slip-resistant.
- Cleaning and maintenance of the product may only be carried out by adults.
- Do not immerse the product in water or other liquids.
- Store the product in a dry and dark place.
- If there is any sign of damage to the product, stop using it immediately.
- Do not attempt to repair the product yourself.

Specifications

- Size: 30 x 30 x 3 cm
- LCD display
- Automatic shut-off (45 sec. +/- 5 sec.)
- Max. load: 180 kg
- Battery-free, kinetic bathroom scale
- Switch between kg, lb and st

Kinetic function

- The bathroom scale is battery-free and uses kinetic energy to power up. Simply step on the scale to generate energy and turn it on.

How to use

- Step directly onto the scale. Do not step on the display.
- Stand still and wait a few seconds.
- Your current weight will be shown on the display.
- In case of overload, the error code ERR will be shown on the display.
- The scale will switch off automatically after about 45 seconds.
- You can make a new measurement by waiting for the scale to have measured the first time (when the display constantly shows the first weight measured after stepping off) or wait for the scale to have switched off and then step on the scale again.

Change units

- Change units by pressing the button below the scale: kg, lbs and stone.

Maintenance/cleaning

- Wipe the bathroom scale with a firmly wrung cloth.

Electrical and electronic equipment (EEE) contains materials, components and substances that can be dangerous and harmful to human health and the environment when waste electrical and electronic equipment (WEEE) is not disposed of properly.

Products marked with the "crossed out bin" are electrical and electronic equipment. The crossed bin symbolizes that waste from electrical and electronic equipment must not be disposed of together with unsorted household waste, but must be collected separately.

To this end, all municipalities have established collection schemes where waste electrical and electronic equipment can be handed in free of charge by citizens at recycling stations or other collection points or collected directly from households. Further information must be obtained from the municipality's technical administration.

PO no.: 109190
Article no.: 11335847

In case of problems or questions regarding the product, please contact the manufacturer: Salling Group, Rosbjergvej 33, DK-8220, sallinggroup.com

Please keep the user guide for future use.

IP44 CE



KINETIC BATHROOM SCALE
USER GUIDE

Please read the user guide carefully before use.