INSTRUCTIONS

Mode d'emploi • Gebrauchshinweise • Instrucciones de uso
Istruzioni per l'utilizzo • Gebruiksaanwijzingen • Instruções de utilização

DONNEZ OU RECYCLEZ — BOUCHERIE · MAGASIN · DÉCHETERIE

Plus d'infos sur quefairedemesdechets.fr

(GB) Use 2 x 1.5v type AA batteries. Take care to fit batteries observing the plus & minus markings. Replace all used batteries at the same time. Do not mix used and new batteries, rechargeable, different types (alkaline or carbon zinc), or different brands of batteries. Only use batteries of the same type. Non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be removed from the product before being charged. Rechargeable batteries are only to be charged under adult supervision. The supply terminals are not to be short circuited. Exhausted batteries are to be removed immediately. To insert / replace batteries: Unscrew battery cover and insert batteries, observing polarity guide. Ensure battery cover is securely screwed in place before use. The crossed out wheelie bin symbol on this product is to remind you that waste electrical and electronic products, batteries and accumulators should not be disposed of with household waste. If you are unable to re-use or recycle your article it should be disposed of at a civic amenity site/local authority recycling facilities. Packaging (and instructions if included) must be kept since they contain important information.

(FR) [illegible]

(DE) [illegible]

(ES) [illegible]

(IT) [illegible]

(NL) [illegible]

(PT) [illegible]

(CZ) [illegible]

(DK) [illegible]

(FI) [illegible]

(GR) [illegible]

(HU) [illegible]

(NO) [illegible]

(PL) [illegible]

(HR) [illegible]

(SK) [illegible]

(SE) [illegible]

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

FUNCTIONS

Fonction • Funktion • Función
Funzione • Functie • Função



© 2025 Mojang AB. All Rights Reserved. Minecraft, the Minecraft logo, the Mojang Studios logo and the Creeper logo are trademarks of the Microsoft group of companies.

MINECRAFT.NET

UK CA CE

UK ONLY — Recycle

DESIGNED IN THE UK
PALADONE
PALADONE PRODUCTS LTD
APEX HOUSE, DOLPHIN WAY
SHOREHAM-BY-SEA
WEST SUSSEX, BN43 6NZ, UK
350, CHEMIN DU PRÉ NEUF, SUITE COV 64877, 38350, LA MURE, FR
PALADONE.COM

PALADONE

WORKING TITLE: WOLF LIGHT

DATE OF CREATION: 28/10/24

This image remains the intellectual copyright of Paladone Products Ltd

MINECRAFT

PANTONES / FINISHES:

BLACK
1 COLOUR (1C)

CUTTERGUIDE:

INDICATES CUT

FLAT DIMENSIONS:
148MM (W) X 210MM (H)