

## EN

Failure to follow these instructions could result in serious INJURY !

Warning! Keep away from fire.

Adults set-up required.

Adults supervision required at all times during use.

Not suitable for adults. Warning! Maximum age 5 years.

Not suitable for hiring or commercial use.

Warning! Only for domestic use. Outdoor use.

1. Set-up and dismantling must be done by an adult.

2. Set up away from water and any potential fire hazards. Keep the blower away from water supply in a dry place during use.

3. The product may not be used outside in rainy and/or lightning conditions or if winds exceed 40km/h (25 MPH). Sudden gusts of wind may lift the product off the ground.

4. Rest the product on a smooth and level surface away from any sharp objects.

5. Exceeding the weight limit may damage the product as well as its function. Serious injury or death may also be resulted.

6. Never slide down head first to avoid the risk of serious injury or death. Keep arms away from the two sides of the slide when sliding down to avoid a risk of skin injuries.

7. Keep children away from the blower while in use.

8. Air leak from the seams is needed because the product is inflated by constant air flow and this leakage is required to stop the product becoming over inflated.

9. Product should periodically be examined for potentially unsafe conditions such as damage to blower, power cord, or plug.

10. Do not drag on concrete or other rough surfaces.

11. Do not use outdoors during strong winds or heavy rain.

12. Store the product and the blower indoors when not in use.

|                                                                                                                                                                                                                                           |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>EN</b>                                                                                                                                                                                                                                 |
| Warning! Maximum 2 players at a time for the whole product. Maximum 2 children at a time for the inflatable part. Age 3+. Maximum total weight limit for the inflatable part 150 lbs (68 kgs). Maximum individual weight 75 lbs (34 kgs). |
| Player's height maximum 4 feet (120 cm ), minimum 3 feet (90 cm).                                                                                                                                                                         |
| To prevent choking hazards, do not eat or drink while inside.                                                                                                                                                                             |
| Before entering, remove eyeglasses,watch,jewelry.                                                                                                                                                                                         |
| No tumbling or flipping.                                                                                                                                                                                                                  |
| No sharp objects.                                                                                                                                                                                                                         |
| No rough play. Keep hands away from net.                                                                                                                                                                                                  |
| No shoes.                                                                                                                                                                                                                                 |

## DK

Følger man ikke disse instruktioner, kan det resultere i alvorlig PERSONSKADE.

Advarsel! Holdes væk fra åben ild.

Skal sættes op af en voksen.

Ved brug skal der altid være en voksen til stede.

Må ikke bruges af voksne. Advarsel! Maks. alder: 5 år.

Må ikke bruges til udlejning til erhverv eller institutioner.

Advarsel! Kun til udendørs og privat brug.

1. Skal sættes op og monteres af en voksen.

2. Produktet skal holdes tørt og køligt, og skal derfor placeres væk fra vand, sumpede områder og risiko for brandfare. Sørg for at blæseren er tør, når den er i brug.

3. Brug aldrig produktet, når det regner, lyner, tordener eller blæser mere end lyn- og tordenvejr Dette produkt må ikke blive brugt udenfor hvis det regner, lyner eller blæser mere end 10 m/s. Kraftige vindstød kan løfte produktet og udgøre risiko for personskade.

4. Placer produktet på et jævnt og glat underlag - uden nogle skarpe genstande.

5. Overstiges vægtgrænsen, kan produktet og dets funktion ødelægges. Dette kan resultere i en alvorlig personskade eller død.

6. For at undgå alvorlige skader eller dødsulykker, må man aldrig rutsje ned med hovedet først. Under rutsjeturen skal armene holdes væk fra kanterne for at undgå hudafskrabninger og andre skader.

7. Sørg for at børnene ikke er i nærheden af blæseren, når den er i brug.

8. Der vil altid slippe lidt luft ud i syningerne, da dette produkt konstant bliver pustet op og denne utæthed derfor er nødvendig, for at der ikke skal komme for meget luft i produktet.

9. Produktet skal jævnligt tjekkes for mulige farer, så som skader på blæseren, ledninger eller stik.

10. Produktet skal ikke trækkes over beton eller andre ujævne eller skarpe overflader.

11. Må ikke bruges udendørs, når det regner eller blæser kraftigt.

12. Produktet og blæseren skal opbevares indendørs, når de ikke er i brug.

|                                                                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>DK</b>                                                                                                                                                                                                                         |
| Advarsel! Produktet må bruges af maks. 2 personer ad gangen. Den oppustelige del må bruges af maks. 2 personer ad gangen. Anbefalet alder: Fra 3 år. Maks. belastning for den oppustelige del: 68 kg. Maksvægt per person: 34 kg. |
| Anbefalet højde per person: Min.90 cm og maks. 120 cm.                                                                                                                                                                            |
| For at undgå kvælningsfare må man ikke spise eller drikke, når man bruger produktet.                                                                                                                                              |
| Tag briller, ure og smykker af inden brug.                                                                                                                                                                                        |
| Ingen saltomortale eller akrobatik.                                                                                                                                                                                               |
| Ingen skarpe genstande.                                                                                                                                                                                                           |
| Ingen voldsom leg. Hold hænderne væk fra nettet.                                                                                                                                                                                  |
| Ingen sko.                                                                                                                                                                                                                        |