




SHARK 3



Please read this instruction manual carefully before using, as it contains all the information you need to know about how to use this product correctly with fun. Colors and contents may vary from instruction.

HOW TO CHARGE

Built-in 3.7V 500mAh lithium battery



USB charging cable

Charging port


Move the car switch to the OFF side. Plug the USB cable into the charger, and plug the other part into the charging port on the car for charging.

REMEMBER: WAIT 10-15 MINUTES FOR THE BATTERY TO COOL DOWN BEFORE CHARGING IT.


Do not use the quick-charge charging device to charge, to avoid burning out the USB charging cable.

Charge by USB: about 1.5 hours;
 Playing time: about 30 minutes;
 Control distance: about 25 meter;
 Battery capacity and voltage: 500 mAh, 3.7V.

BATTERY INSTALLATION



Open the battery cover of controller, install 2 x 1.5V "AA" batteries, close the cover.



THE BASIC OPERATION OF THE PRODUCTS

① Forward




② Backward




③ Rollover stunts



④ Upright with the front wheel forward hovering counterclockwise



⑤ Upright with the front wheel facing forward, circling clockwise



Batteries should be installed by an adult. Remember to position + and - correctly. Do not mix old and new batteries or different types of batteries. Do not attempt to recharge batteries which are not rechargeable. Remove batteries if the product is not in use for some time. Do not short-circuit the battery contacts. Rechargeable batteries are only to be charged under adult supervision. Rechargeable batteries are to be removed from the toy before being charged. Exhausted batteries are to be removed from the toy. Please keep this information for future reference.



For environmental reasons, electrical equipment must be disposed separately from household waste. Contact the municipality for the nearest collection point.

Produced and Imported by:
 MaxToys ApS, Bjarkevej 10B, Skovby, DK-8464 Gatten
 info@maxtoys.dk



Læs denne brugsanvisning grundigt før brug, da den indeholder alle relevante oplysninger.

Farver og indhold kan variere fra illustrationerne.

SÅDAN OPLADER DU

Indbygget 3,7V
500mAh lithiumbatteri


USB
opladerkabel

Flyt bilens tænd/sluk-knap til OFF-positionen. Sæt USB-kablet i et opladerstik, og stik den anden ende i opladningsporten på bilen for at oplade.

HUSK: VENT 10-15 MINUTTER, FØR DU OPLADER BATTERIET, SÅ DET KAN KØLE AF.


Brug ikke en hurtigoplader til opladning, da dette kan beskadige USB-opladerkablet.

Opladning via USB: ca. 1,5 timer;
Køretid: ca.30 minutter;
Styringsafstand: ca. 25 meter;
Batterikapacitet og spænding: 500 mAh, 3,7V.




Tænd/Sluk — Lys

BATTERI INSTALLATION



Åbn batteridækslet på fjernbetjeningen, indsæt 2 x 1,5V AA-batterier, og luk dækslet.



BRUGSANVISNING TIL PRODUKTET

① Fremad



② Baglæns



③ Rulle-stunts



④ Oprejst med forhjulet fremad, roterende mod uret



ROTER



⑤ Oprejst med forhjulet fremad, roterende med uret



ROTER



Isætning af batterier bør foretages af en voksen. Husk at vende + og - korrekt. Bland aldrig gamle og nye batterier eller forskellige batterityper. Forsøg aldrig at genoplade ikke-genopladelige batterier. Tag batterierne ud, hvis varen ikke anvendes i en længere periode. Kortslut ikke batterikontakterne. Genopladelige batterier må kun oplades under voksen tilsyn. Genopladelige batterier skal fjernes fra legetøjet, før de oplades. Obrugte batterier skal fjernes fra legetøjet. Opbevar denne vejledning til senere brug.



Af hensyn til miljøet skal elektrisk udstyr bortskaffes særskilt fra husholdningsaffald. Kontakt kommunen for nærmeste indsamlingssted.

Importør af og produceret for:
MaxToys ApS, Bjarkevej 10B, Skovby, DK-8464 Galten
info@maxtoys.dk