


















Lindhus










Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба


Name • Nom • Nome • Naam Nazwa • Jméno • Názov • Név Denumire • Ísim • Название				
Nr. • No. • N° • Номер • Č • Sz				
Typ • Type • Tip • Típus • Tipo Тип				
				
				
AX3			X1	X2
BX1			√	
CX1				√
DX1			√	
EX1				√
FX2			X1	X1
GX3			X1	X2
HX8			√	
IX1			√	
JX1			√	

			1/2	2/2
KX1			✓	
LX8			✓	
MX8			✓	
NX2			✓	
QX16		M6x35mm	✓	
RX5		M6x25mm	✓	
SX8		M6x35mm	✓	
TX1			✓	







1




2




3




4




5




6



7





8





9



①



②



③



④

