



Ax1



Bx1



Cx1



Dx7





Ex1



Fx8



Gx3



© Button C:

Color Changing Key with 6 optional colors

Static variable single color/flowing loop color

Ⓜ Button M: Mode Control Key

press **M** once:entre mode 1, RGB light up,
press **C**, 6 colors change, and then dazzling mode.

press **M** twice:entre mode 2, special volume cotrol mode

press **M** triple:switch off

