



ASSEMBLY INSTRUCTION
MONTERINGSVEJLEDNING
MONTERINGSANVISNING
KOKOAMISOHJEET
INSTRUÇÕES DE MONTAGEM
INSTRUCCIONES DE MONTAJE



DELUXE 4 BURNER BLACK GAS GRILL WITH SEARING SIDE BURNER
DELUXE 4-BRÆNDER RUSTFRI STÅL GASGRILL MED SIDEBRÆNDER TIL STEGNING
DELUXE 4-BRENNAR RUSTFRI STÅL GASSGRILL MED SIDEBRÄNNAR FÖR STEIKING
DELUXE 4-LIEKKINEN RUOSTUMATTOMASTA TERÄKSESTÄ VALMISTETTU KAASUGRILLI SIVUPAISTOLEVYLLÄ
GRELHADOR A GÁS DE 4 FOGAREIROS DE AÇO INOXIDÁVEL DELUXE COM FOGAREIRO LATERAL PARA SELAR
PARRILLA DE GAS DE ACERO INOXIDABLE DELUXE DE 4 QUEMADORES CON QUEMADOR LATERAL PARA SELLAR

DELUXE 4 BURNER BLACK GAS GRILL WITH SEARING SIDE BURNER
DELUXE SORT GASGRILL MED 4 BRÆNDERE OG SIDEBRÆNDER
DELUXE GASSGRILL MED 4 BRENNERS SVART MED SIDEBRUNNER
DELUXE-TASON 4-POLTTIMELLINEN MUSTA KAASUGRILLI SIVUPAISTETTAVALLA POLTTIMEN KANSSA
CHURRASQUEIRA A GÁS PRETA DELUXE COM 4 QUEIMADORES E QUEIMADOR LATERAL
PARRILLA DE GAS NEGRA DE LUJO DE 4 QUEMADORES CON QUEMADOR LATERAL

MODEL / MODELL / MODEL / MODELL / MALLI / MODELO
720-0830XR / 720-0830XY



For outdoors use only. / Kun til udendørs brug. / Kun for /
utendørs bruk. / Vain ulkokäyttöön. / Apenas para uso
externo. / Sólo para uso en exteriores.

NEXGRILL®

Part Number:
19001232A0 / 19001233A0

CE 2531DP-0191
2531-25

TOOLS NEEDED / NØDVENDIGE VÆRKTØJER / VERKTØY SOM TRENGS / TARVITTAVAT TYÖKALUT / FERRAMENTAS NECESSÁRIAS / HERRAMIENTAS NECESARIAS



Some parts come with Screws preinstalled.
Loosen and tighten for final assembly.


Nogle dele leveres med forudinstallerede
skruer. Løsn og spænd for endelig montering.

Noen deler leveres med forhåndsmonterte
skruer. Løsne og stram for endelig montering.

Joissakin osissa on valmiiksi asennetut ruuvit.
Löysää ja kiristä ruuvit lopullista kokoonpanoa
varten.


Algumas peças vêm com parafusos pré-
instalados. Desaperte e aperte para a
montagem final.

Algunas piezas vienen con tornillos
preinstalados. Afloje y apriete para el
ensamblaje final.




HARDWARE PACKAGE LIST / LISTE OVER HARDWAREPAKKER / LISTE OVER MASKINVAREPAKKER / LAITTEISTOPAKETTIEN LUETTELO / LISTA DE PACOTES DE HARDWARE / LISTA DE PAQUETES DE HARDWARE


Screw
Skrue
Skru
Ruuvi
Parafuso
Tornillo
1/4-20 x 1/2"




Screw
Skrue
Skru
Ruuvi
Parafuso
Tornillo
5/32 - 32 x 25/64"




Flat Washer
Flad skive
Flat skive
Litteä aluslevy
Arruela plana
Arandela plana
1/4"



Flat Washer
Flad skive
Flat skive
Litteä aluslevy
Arruela plana
Arandela plana
1/4 - 20 x 25/32"


















Screw
Skrue
Skru
Ruuvi
Parafuso
Tornillo
1/4 - 20 x 25/32"
















QUESTIONS, PROBLEMS, MISSING PARTS? PLEASE CALL:
SPØRGSMÅL, PROBLEMER, MANGLENDE DELE? RING VENLIGST:
SPØRSMÅL, PROBLEMER, MANGLENDE DELER? RING:
KYSYMYKSIÄ, ONGELMIA TAI PUUTTUVIA OSIA? SOITA:
DÚVIDAS, PROBLEMAS, PEÇAS EM FALTA? LIGUE PARA:
¿PREGUNTAS, PROBLEMAS, PIEZAS FALTANTES? LLAME AL:

+49 5251 875 6174 | ServiceDE@nexgrill.de (DE)
+45 60 20 60 71 | ServiceDK@nexgrill.com (DK)



PACKAGE PARTS LIST



1 	2 x2 	3 
4 x2 	5 x2 	6 
7 	8 	9 
10 	11 	12 
13 x2 	14 	15 






ASSEMBLY INSTRUCTION / MONTERINGSVEJLEDNING / MONTERINGSANVISNING /
KOKOAMISOHJEET / INSTRUÇÕES DE MONTAGEM / INSTRUCCIONES DE MONTAJE








5




6




7




8




9




10





11





12




13





14




15




16




17




18




19




20




21




22




23





24




25



26




27




28


**Battery NOT included
Batteri IKKE inkluderet
Batteri IKKE inkludert
Akku EI sisällytoimitukseen
Bateria NÃO incluída
Batería NO incluida**





29




30



31



32




33


B

x2


22




34




35




36




37





38




39




40




41




42






43





44




45




46




47




48



49



50





QUESTIONS, PROBLEMS, MISSING PARTS? PLEASE CALL:
SPØRGSMÅL, PROBLEMER, MANGLENDE DELE? RING VENLIGST:
SPØRSMÅL, PROBLEMER, MANGLENDE DELER? RING:
KYSYMYKSIÄ, ONGELMIA TAI PUUTTUVIA OSIA? SOITA:
DÚVIDAS, PROBLEMAS, PEÇAS EM FALTA? LIGUE PARA:
¿PREGUNTAS, PROBLEMAS, PIEZAS FALTANTES? LLAME AL:

+49 5251 875 6174 | ServiceDE@nexgrill.de (DE)
+45 60 20 60 71 | ServiceDK@nexgrill.com (DK)

MODEL / MODELL / MODEL / MODELL / MALLI / MODELO
720-0830XR / 720-0830XY

THIS ITEM IS INTENDED FOR OUTDOOR DOMESTIC USE ONLY. NOT FOR COMMERCIAL USE

NEXGRILL®

Part Number:
19001232A0/ 19001233A0

CE 2531DP-0191
2531-25