

BRUGSANVISNING / INSTRUCTION MANUAL

ALKOHOLDISPENSER / ALCOHOL DISPENSER / 11106788



SÅDAN FYLDES OG BRUGES ALKOHOLDISPENSEREN


1. Drej toppen 90 grader mod uret, og løft den opad.




2. Fyld alkoholdispenseren med din yndlingsspiritus, sæt derefter toppen tilbage i åbningen, og drej den med uret for at låse den på plads.



3. Fjern dysen fra krogen på alkoholbeholderen, og skub håndtaget for at fylde glasset med spiritus.




4. Sæt dysen tilbage på krogen opad for at forhindre lækage.




RENGØRINGS- OG PLEJEINSTRUKTIONER TIL ALKOHOLDISPENSER

KUN HÅNDVASK


1. Drej toppen 90 grader mod uret, og løft den opad.




2. Fyld alkoholdispenseren med varmt sæbevand. Skub håndtaget for at dræne vandet gennem spritdispenseren. Gentag flere gange for at rengøre grundigt. Vask også toppen separat.



3. Fyld alkoholdispenseren med varmt, rent vand. Skub håndtaget for at dræne vand gennem pumpen. Gentag flere gange for at skylle alle sæberester ud.



4. Placer alkoholbeholderen på hovedet på en sikker overflade eller tørrestativ, indtil den er helt tør. Når den er tør, skal du placere toppen tilbage på alkoholdispenseren.



TEKNISKE DATA

Artikelnr. 11106788

Kapacitet: 950 ml

PRODUCENT

Epiq ApS

Krøyer Kielbergs Vej 3, 3. th

8660 Skanderborg, Danmark

www.epiq.dk


Vi tager forbehold for trykfejl.

HOW TO FILL AND USE THE ALCOHOL DISPENSER


1. Turn the top 90 degrees counterclockwise and lift it upwards.




2. Fill the alcohol dispenser with your favorite liquor, then place the top back into the opening and turn it clockwise to lock it into place.



3. Remove the nozzle from the hook on the alcohol dispenser and push the handle to fill the glass with liquor.




4. Place the nozzle back on the hook facing upward to prevent leaking.




GAS PUMP CLEANING AND CARE INSTRUCTIONS

HAND WASH ONLY


1. Turn the top 90 degrees counterclockwise and lift it upwards.




2. Fill the alcohol dispenser with warm, soapy water. Push the handle to drain the water through the alcohol dispenser. Repeat several times to thoroughly clean. Wash the top separately as well.



3. Fill the alcohol dispenser with warm, clean water. Push the handle to drain water through the pump. Repeat several times to rinse out all soap residues.



4. Place the alcohol dispenser upside down on a secure surface or drying rack until completely dry. Once dry, place the top back on the alcohol dispenser.



TECHNICAL DATA

Article No. 11106788

Capacity: 95ml

PRODUCER

Epiq ApS

Krøyer Kielbergs Vej 3, 3. th

8660 Skanderborg, Denmark

www.epiq.dk

We cannot be held responsible for any printing errors.