WALL CHARGER
Size: 80x90 mm
Manual

Inkluderer

- Vægoplader

Anvendelse

- Tilslut vægoplader til stikkontakt.
- Sæt den elektriske tandbørste i opladeren.
- Opladning starter automatisk. Se på tandbørstens LED indikator, hvis den har en, for ladestatus.

Kompabilitet

Oral-B IO4/5/6, D12, S12, S18, D10, D16, D17, D18, D19, D20, D29, D34, D36 /OC18, OC20 / D12013, D12013w, D12523 serier / Professional 500, 600, 1000, 2000, 2500, 3000, 4000, 5000, 7000, 7500, 3709, 3728, 3737, 3756, 4736, 4717, 4729, 4733, 6500, 8000, 8850, 8900, 9000, 9000s Genius 6000, 8000

Specifikationer

- Input: 100-240V AC 50-60 Hz
- Output: 5V 0,06A
- Effekt: 0,3W
- Klassificering: IP46

Vedligeholdelse/rengøring

- Sluk for kontakten når produktet ikke er i brug.
- Træk produktet ud af stikkontakten inden rengøring.
- Tørres af med en hårdt opvredet klud.

ADVARSEL/sikkerhedsforanstaltninger

- Læs hele manualen før brug.
- Kun til indendørs brug.
- Må ikke nedsænkes i vand eller andre væsker.
- Placer ikke opladeren, hvor den kan falde ned i badekar, håndvask eller andre beholdere med vand.
- Rør aldrig opladeren med våde hænder.
- Brug ikke opladeren, hvis den er beskadiget, eller hvis stikket eller kabinettet har synlige skader.
- Forsøg ikke at åbne, reparere eller modificere opladeren.
- Hold opladeren utilgængelig for små børn. Produktet er ikke legetøj.
- Må kun anvendes med den angivne netspænding.
- Opladeren må ikke installeres eller anvendes i brusekabinen eller andre steder, hvor den udsættes for direkte vandstråler.

Elektrisk og elektronisk udstyr (EEE) indeholder materialer, komponenter og stoffer, der kan være farlige og skadelige for menneskers sundhed og for miljøet, når affaldet af elektrisk og elektronisk udstyr (WEEE) ikke bortskaffes korrekt.

Produkter, der er mærket med nedenstående "overkrydsede skraldespand", er elektrisk og elektronisk udstyr. Den krydsede skraldespand symboliserer, at affald af elektrisk og elektronisk udstyr ikke må bortskaffes sammen med usorteret husholdningsaffald, men skal indsamles særskilt.

Til dette formål har alle kommuner etableret indsamlingsordninger, hvor affald af elektrisk og elektronisk udstyr gratis kan afleveres af borgerne på genbrugsstationer eller andre indsamlingssteder eller hentes direkte fra husholdningerne. Nærmere information skal indhentes hos kommunens tekniske forvaltning.

PO nr.: 109212
Vare nr.: 11352004

I tilfælde af problemer eller spørgsmål til produktet, kontakt da venligst producenten: Salling Group, Rosbjergvej 33, DK-8220, sallinggroup.com

Gem venligst manualen til fremtidig brug.

IP46



VÆGOPLADER
MANUAL

Læs venligst manualen grundigt inden brug.

Includes

- Wall charger

How to use

- Plug the wall charger into an electrical outlet.
- Place the electric toothbrush in the charger.
- Charging will begin automatically. Check the toothbrush's LED indicator, if it has one, for charging status.

Compatibility

Oral-B IO4/5/6, D12, S12, S18, D10, D16, D17, D18, D19, D20, D29, D34, D36 /OC18, OC20 / D12013, D12013w, D12523 series / Professional 500, 600, 1000, 2000, 2500, 3000, 4000, 5000, 7000, 7500, 3709, 3728, 3737, 3756, 4736, 4717, 4729, 4733, 6500, 8000, 8850, 8900, 9000, 9000s Genius 6000, 8000

Specifications

- Input: 100-240V AC 50-60 Hz
- Output: 5V AC 0.06A
- Power: 0.3W
- Classification: IP46

Maintenance/cleaning

- Turn off the switch when the product is not in use.
- Unplug the product from the outlet before cleaning.
- Wipe with a hard wrung cloth.

WARNING/Safety precautions

- Read the entire manual before use.
- For indoor use only.
- Do not immerse in water or other liquids.
- Do not place the charger where it can fall into a bathtub, sink or other container of water.
- Never touch the charger with wet hands.
- Do not use the charger if it is damaged or if the plug or housing has visible damage.
- Do not attempt to open, repair or modify the charger.
- Keep the charger out of the reach of small children. The product is not a toy.
- Only use the specified mains voltage.
- Do not install or use the charger in a shower or other location where it is exposed to direct water jets.

Electrical and electronic equipment (EEE) contains materials, components and substances that can be dangerous and harmful to human health and the environment when waste electrical and electronic equipment (WEEE) is not disposed of properly.

Products marked with the "crossed out bin" are electrical and electronic equipment. The crossed bin symbolizes that waste from electrical and electronic equipment must not be disposed of together with unsorted household waste, but must be collected separately.

To this end, all municipalities have established collection schemes where waste electrical and electronic equipment can be handed in free of charge by citizens at recycling stations or other collection points or collected directly from households. Further information must be obtained from the municipality's technical administration.

PO no.: 109212
Article no.: 11352004

In case of problems or questions regarding the product, please contact the manufacturer: Salling Group, Rosbjergvej 33, DK-8220, sallinggroup.com

Please keep the user guide for future use.

IP46



WALL CHARGER
USER GUIDE

Please read the user guide carefully before use.