

**TREASURE
PRODUCTS**

detectors with a pulse

PI-iking™ 730

Pinpointer Metal Detector



Thank you for choosing the PI-iking™ 730 pinpointer metal detector made by TianXun, the originators of the vibrating pinpointer.

The simple to use design and modern electronics make it easy to locate elusive targets in any environment including grass, mud, dirt, sand, black sand, even fresh or salt water.

PRODUCT FEATURES

- **Communicates with vibration** The PI-iking™ signals with pulses of vibration when a target is located.
- **Pulse Induction Technology (PI)** –Allows hunting in salt water or in any type of soil, including black sand.
- **Detection depth stability** –Advanced circuitry maintains detection distance throughout the life of the battery.
- **True target direction** – Detects at the tip only, not along the shaft, enabling precision target pinpointing.
- **Target distancing** – As the probe tip gets closer to the target the pulses of vibration will continue to increase.
- **Automatic tuning** –The state of the art microprocessor controlled design requires no adjustments of any kind.
- **Tilt On/Off** –Turns on and off when pointed upward or will automatically turn itself off one minute after last pulse.
- **Waterproof** –Sealed design allows hunting in the rain or even under water to a depth of 100 feet.

BATTERY INSTALLATION

When the knob of the battery compartment seal is rotated clockwise, the plug expands and presses against the inside wall, sealing the unit.

To open the battery compartment seal, rotate the knob counter-clockwise a few turns, then pull to remove.

Connect a standard 9v battery to the battery clip and insert the battery into the detector, clip side first.

To replace the seal, insert all the way in. Then turn the knob clockwise until hand tight to assure a water-tight seal.



Before submerging the PI-iking™ make sure the battery compartment seal is secure.

OPERATING INSTRUCTIONS

Turn on: Point the probe tip up for at least one second. Two short pulses of vibration indicate the probe is on.

Turn off: After use, point tip up for at least one second. Two long pulses of vibration indicate the probe is off.

Automatic off: Automatically occurs one minute after last pulse. Turn off is indicated by two long pulses of vibration.

Low battery turn off: When the battery is low the unit will shut down automatically indicated by four long pulses.

Operation: The PI-iking™ 730 communicates through pulses of vibration. The pulses of vibration increase in quantity the closer the probe tip is to the target.

The quantity of pulses is proportional to the target size and distance. The bigger the target, or the closer the probe tip is to the target, the higher the pulse count.

Probe the soil in different locations until you detect the target. The PI-iking™ 730 detects targets at the tip only. This allows you to precisely locate the target.

IMPORTANT NOTES

The probe communicates its proximity to the target only one time per detection. Move the probe tip slightly away and then re-approach the target to get the next detection.

As with any new detector you should practice with known targets to develop your pinpointing technique.

The PI-iking™ is a robust unit. However, it should not be used as a pry-bar or digging tool.

False detections may occur if the coil of your primary detector is too close to the Vibra-iking™

HELPFUL HINTS

If your primary detector indicates that the target is near the surface, probe the surface before digging. To locate deeper targets loosen the ground with a suitable digging tool before using the probe.

When hunting in a lawn, rather than digging a large hole, insert a screwdriver or similar tool into the ground from several angles to push the grass and roots aside to form a slot large enough to insert the probe. Then probe the sides of the slot to locate the target.

CARE AND MAINTANANCE

Your PI-iking™ is a sensitive electronic instrument. Although it is rugged, care in transporting and handling will extend its life and result in optimum performance.

When the PI-iking™ is off there is no drain on the battery. However, if stored for long periods of time, we recommend that the battery be removed to prevent damage to the detector due to a potential battery leak.



Always use high quality batteries such as alkaline or nickel metal hydride (NiMH).

Other fine products from Tianxun

pi-iking™ 740

- Hearing impaired?
- Don't like headphones?
- Replace sound with vibration.



PI-iking™ 750

- Pulse Induction Metal Detector
- Signals with vibration and light
- Waterproof – Submersible
- Great for divers!



PI-iking™ 730 Specifications

- Detection Type • Pulse Induction
- Search Mode • All metal
- Overall Length • 14 inches (35 cm)
- Tip Diameter • 1 inch (2,5 cm)
- Weight • 230 grams
- Power • Standard 9 volt battery
- Warranty • 1 year
- Holster • Included

Specifications are subject to change without notice.

PRODUCTS LIMITED WARRANTY

What does this warranty cover?

Our products warrant that its products are free from defects in material and workmanship under normal use for a period of one (1) year from the date of purchase.

Warranty extends only to original purchaser and is not transferable.

What is not covered by this warranty?

This warranty does not cover any accessories, or any consumables, as to which there shall be no warranty or replacement. This warranty does not cover conditions or damages caused by accidents, alterations or misuse. In addition, damage due to normal wear and tear is not covered by this warranty.

What is needed to keep the warranty in service?

You must provide proof of purchase as a condition of receiving warranty service. Your dated sales receipt, showing the date of purchase of your product is your proof of the purchase date.

What will Products do to correct problems?

TianXun will repair or replace any defective, nonconforming, or malfunctioning product or any component thereof.

**TREASURE
PRODUCTS**

detectors with a pulse

PI-iking™ 740

Pinpointer Metal Detector



Thank you for choosing the PI-iking™ 740 pinpointer metal detector made by TianXun, the originators of the vibrating pinpointer.

PRODUCT FEATURES

- **Communicates with vibration & light** – When a target is located the PI-iking™ 740 signals with pulses of vibration and flashes of bright light from a blue L.E.D.
- **Pulse Induction Technology (PI)** – Allows hunting in salt water or in any type of soil, including black sand.
- **Detection depth stability** – Advanced circuitry maintains detection distance throughout the life of the battery.
- **Target distancing** – As you get closer to the target the pulses of vibration and light will increase in quantity.
- **Automatic tuning** – The state of the art microprocessor controlled design requires no adjustments of any kind.
- **Waterproof** – Sealed design allows hunting in the rain or under water to a depth of 100 feet. Great for divers!

BATTERY INSTALLATION

When the knob of the battery compartment seal is rotated clockwise, the plug expands and presses against the inside wall, sealing the unit.

To open the battery compartment seal, rotate the knob counter-clockwise a few turns, then pull to remove.

Connect a standard 9v battery to the battery clip and insert the battery into the detector, clip side first.

To replace the seal, insert all the way in. Then turn the knob clockwise until hand tight to assure a water-tight seal.



Before submerging the PI-iking™ make sure the battery compartment seal is secure.

OPERATING INSTRUCTIONS

Turn on sequence: Hold unit with the tip up for at least 3 seconds. Light will blink. Two short pulses of vibration and a steady dim light indicate unit is on.

Turn off sequence: After use, hold unit with tip up for at least 3 seconds. Light will blink. Two long pulses of vibration and no light indicate the unit is off.

Low battery turn off: When the battery is low the unit will shut down automatically indicated by four long pulses.

Operation: The PI-iking™ 740 communicates through pulses of vibration and bright light. These pulses increase in quantity the closer the tip is to a target.

The quantity of pulses is proportional to the target size and distance. The bigger the target, or the closer the probe tip is to the target, the higher the pulse count.

You can either probe the soil or sweep the head side to side on the surface you are detecting. The PI-iking™ 740 directs its detection field straight out the tip. This allows you to precisely locate the target.

IMPORTANT NOTES

Raising the detectors tip up while in use will start the turn-off sequence, indicated by a blinking light. Lower the detectors tip within 3 seconds to continue detecting.

Unit will not detect when the light is blinking in either the turn-on or turn-off sequence.

As with any new detector you should practice with known targets to develop your technique.

HELPFUL HINTS

If you continue to hold the detector with the tip up after turn on, then the detector will remain on indefinitely. This feature may be useful if searching with the detector in a vertical position is necessary.

You can secure the PI-iking™ 740 to your wrist using the attached wrist strap. To adjust fit, press down on the cord lock button and move it to the desired location.

CARE AND MAINTANANCE

Your PI-iking™ 740 is a sensitive electronic instrument. Although it is rugged, care in transporting and handling will extend its life and result in optimum performance.

When the PI-iking™ 740 is off there is no drain on the battery. However, if stored for long periods of time, we recommend that the battery be removed to prevent damage to the detector due to a potential battery leak.

If the detector has been exposed to salt water always rinse with fresh water and check the battery compartment for any leaks. If water has entered the battery compartment carefully wipe dry and leave open until completely dry.



Always use high quality batteries such as alkaline or nickel metal hydride (NiMH).

Other fine products from Tianxun

PI-iking™ 730

Arms and shoulders tired from swinging that heavy detector?

That's why we created it.
• Fully adjustable



PI-iking™ 750

Pulse Induction Metal Detector

- Signals with vibration and light
- Waterproof – Submersible
- Great for divers!



PI-iking™ 740 Specifications

- Detection Type • Pulse Induction
- Search Mode • All metal
- Alarm Mode • vibration and LED blue light
- Overall Length • 15 inches (38cm)
- Tip Diameter • 2 inch (5cm)
- Weight • 12oz.(375 grams)
- Power • Standard 9 volt battery
- Warranty • 1 year
- Holster • Included
- Wrist strap • Included

Specifications are subject to change without notice.

PRODUCTS LIMITED WARRANTY

What does this warranty cover?

Our products warrant that its products are free from defects in material and workmanship under normal use for a period of one (1) year from the date of purchase.

Warranty extends only to original purchaser and is not transferable.

What is not covered by this warranty?

This warranty does not cover any accessories, or any consumables, as to which there shall be no warranty or replacement. This warranty does not cover conditions or damages caused by accidents, alterations or misuse. In addition, damage due to normal wear and tear is not covered by this warranty.

What is needed to keep the warranty in service?

You must provide proof of purchase as a condition of receiving warranty service. Your dated sales receipt, showing the date of purchase of your product is your proof of the purchase date.

What will Products do to correct problems?

TianXun will repair or replace any defective, nonconforming, or malfunctioning product or any component thereof.

**TREASURE
PRODUCTS**

detectors with a pulse

PI-iking™ 750

Pinpointer Metal Detector



Thank you for choosing the PI-iking™ 750 metal detector made by TianXun. The unique sealed design allows detecting in any environment including grass, mud, dirt, sand, black sand, or even in fresh or salt water.

PRODUCT FEATURES

- **Communicates with vibration & light** –When a target is located the PI-iking™ 750 signals with pulses of vibration and flashes of bright light from a white L.E.D.
- **Pulse Induction Technology (PI)** – Allows hunting in salt water or in any type of soil, including black sand.
- **Detection depth stability** –Advanced circuitry maintains detection distance throughout the life of the battery.
- **Target distancing** – As you get closer to the target the pulses of vibration and light will increase in quantity .
- **Automatic tuning** – The state of the art microprocessor controlled design requires no adjustments of any kind.
- **Waterproof** – Sealed design allows hunting in the rain or under water to a depth of 100 feet. Great for divers!

BATTERY INSTALLATION

When the knob of the battery compartment seal is rotated clockwise, the plug expands and presses against the inside wall of the battery compartment, sealing the unit.

To open the battery compartment seal, rotate the knob counter-clockwise a few turns, then pull to remove.

Connect a standard 9v battery to the battery clip and insert the battery into the detector, clip side first.

To replace the seal, insert all the way in. Then turn the knob clockwise until hand tight to assure a water-tight seal.



Before submerging the PI-iking™ 750 make sure the battery compartment seal is secure.

OPERATING INSTRUCTIONS

Turn on sequence: Hold unit with the search coil up for at least 5 seconds. Light will blink. Two short pulses of vibration and a steady dim light indicate unit is on.

Turn off sequence: After use, hold unit with the search coil up for at least 5 seconds. Light will blink. Two long pulses of vibration and no light indicate the unit is off.

Low battery turn off: When the battery is low the unit will shut down automatically indicated by four long pulses.

Operation: The PI-iking™ communicates through pulses of vibration and bright light. These pulses increase in quantity the closer the search coil is to a target.

The quantity of pulses is proportional to the target size and distance. The bigger the target, or the closer the search coil is to the target, the higher the pulse count.

The detection field projected resembles a cone shape, with the deepest depth of detection in the center of the coil.

Move the search coil in a sweeping motion along the surface of the area you are searching. The slower the sweep the deeper the detection depth.

IMPORTANT NOTES

Raising the detectors coil up while in use will start the turn-off sequence, indicated by a blinking light. Lower the detectors coil within 5 seconds to continue detecting.

Unit will not detect when the light is blinking in either the turn-on or turn-off sequence.

As with any new detector you should practice with known targets to develop your technique.

HELPFUL HINTS

If you continue to hold the detector with the coil up after turn on, then the detector will remain on indefinitely. This feature may be useful if searching with the detectors coil in a vertical position is necessary.

You can secure the PI-iking™ 750 to your wrist using the attached wrist strap. To adjust fit, press down on the cord lock button and move it to the desired location.

CARE AND MAINTANANCE

Your PI-iking™ 750 is a sensitive electronic instrument. Although it is rugged, care in transporting and handling will extend its life and result in optimum performance.

When the PI-iking™ 750 is off there is no drain on the battery. However, if stored for long periods of time, we recommend that the battery be removed to prevent damage to the detector due to a potential battery leak.

If the detector has been exposed to salt water always rinse with fresh water and check the battery compartment for any leaks. If water has entered the battery compartment carefully wipe dry and leave open until completely dry.



Always use high quality batteries such as alkaline or nickel metal hydride (NiMH).

Other fine products from Tianxun

PI-iking™ 730

Arms and shoulders tired from swinging that heavy detector?

That's why we created it.

- Fully adjustable



PI-iking™ 740

Hearing impaired?

Don't like headphones?

Replace sound with vibration.



PI-iking™ 750 Specifications

Detection Type • Pulse Induction

Search Mode • All metal

Alarm Mode • vibration and LED white light

Overall Length • 17 inches (43cm)

Tip Diameter • 4 inch (10cm)

Weight • 1 lb.(450 grams)

Power • Standard 9 volt battery

Warranty • 1 year

Holster • Included

Wrist strap • Included

Specifications are subject to change without notice.

PRODUCTS LIMITED WARRANTY

What does this warranty cover?

Our products warrant that its products are free from defects in material and workmanship under normal use for a period of one (1) year from the date of purchase.

Warranty extends only to original purchaser and is not transferable.

What is not covered by this warranty?

This warranty does not cover any accessories, or any consumables, as to which there shall be no warranty or replacement. This warranty does not cover conditions or damages caused by accidents, alterations or misuse. In addition, damage due to normal wear and tear is not covered by this warranty.

What is needed to keep the warranty in service?

You must provide proof of purchase as a condition of receiving warranty service. Your dated sales receipt, showing the date of purchase of your product is your proof of the purchase date.

What will Products do to correct problems?

TianXun will repair or replace any defective, nonconforming, or malfunctioning product or any component thereof.