



# DC90 Series Control System Specification

Version No: A/o4



## Type Specification

 <p>up button</p> <p>stop button</p> <p>down button</p> <p>DC90</p>	 <p>setting button (P2)</p> <p>The backside of DC90/DC92(A) /DC93/DC94</p>	<ul style="list-style-type: none"> <li>Input voltage: 12V/27A (DC90 DC92(A) DC93 DC94)</li> <li>Input voltage: 3V/CR2430 (DC93A DC94A)</li> <li>Emission Power: 10 milliwatt</li> <li>Work temperature: -10°C -50°C</li> <li>Emission distance: open 200m, two walls 30m</li> <li>Notice: transmitter Do not exposed to moisture and strike, so as not to affect life. When you use transmitter if found emission distance obviously short or less sensitive, please change another same new battery, Please have batteries for recycling.</li> </ul>
--	---	---



Additional  
Function

## Matchable R Tubular Motor Set up



Delete all the datas of the motor and the new emitter has been programmed.



The interval of each button must within 10 seconds of resetting, otherwise the system will restore the original state.

