

KØKKENHEF



INSTRUCTION MANUAL MICROWAVE OVEN

11165137

INTRODUKTION

Mange tak fordi du har valgt et produkt fra Køkkenchef. Dermed har du erhvervet et kvalitetsprodukt som opfylder alle gældende krav til præstation og sikkerhedsstandarder i EU. For at sikre en korrekt behandling og en lang levetid anbefaler vi, at du overholder nedenstående anvisninger.

Du bedes læse vejledningen og især sikkerheds anvisningerne omhyggeligt igennem, inden du tager produktet i brug. Opbevar denne betjeningsvejledning, og overlad altid kun produktet til andre sammen med betjeningsvejledningen.

GENERELLE SIKKERHEDSFORANSTALTNINGER

- Forkert brug af produktet kan medføre personskade og beskadige produktet.
- Anvend kun produktet til det, det er beregnet til. Producenten er ikke ansvarlig for skader, der opstår som følge af forkert brug eller håndtering.
- Anbring altid produktet på et tørt, plant og stabilt underlag på god afstand af bordkant eller lignende.
- Produktet er udelukkende beregnet til husholdningsbrug. Produktet må ikke anvendes til erhvervsbrug.
- Produktet må kun sluttes til 220-240V~, 50/60Hz.
- Produktets motordel/elektronik, ledning og stikket må ikke nedsænkes i vand, og der må ikke trænge vand i motordel/elektronik.
- Rør aldrig ved produktet, ledningen eller stikkontakten med våde eller fugtige hænder.
- Udsæt ikke produktet for direkte sollys, høje temperaturer, fugt, støv eller ætsende stoffer.
- Forlad aldrig produktet, når det er tændt.
- Når produktet er i brug, bør det holdes under konstant opsyn.
- Når produktet bruges skal børn der opholder sig i nærheden af

den altid holdes under opsyn.

- Børn må ikke lege med produktet.
- Produktet kan indeholde skarpe dele og bør derfor opbevares utilgængeligt for børn.
- Brug kun tilbehør, der følger med produktet eller er anbefalet af producenten.
- Produktet må bruges af børn på 8 år eller derover og personer med reducerede fysiske, sensoriske eller mentale evner, eller som mangler erfaring og viden, hvis de er under opsyn eller har modtaget instruktion i sikker brug af produktet og forstår de involverede farer.
- Hold produktet og ledningen uden for rækkevidden af børn under 8 år.
- Rengøring og vedligeholdelse må ikke udføres af børn med mindre de er ældre end 8 år og under opsyn.

LEDNING OG STIK

- Lad ikke ledningen hænge ud over bordkanten.
- Hold ledningen og produktet væk fra varmekilder, varme genstande og åben ild.
- Tag stikket ud af stikkontakten før rengøring, og hvis produktet ikke er i brug. Undlad at trække i ledningen, når du tager stikket ud af stikkontakten, men tag fat om selve stikket.
- Sørg for, at ledningen er rullet helt ud.
- Kontrollér jævnligt, om ledningen eller stikket er beskadiget, og brug ikke produktet, hvis dette er tilfældet, eller hvis det har været tabt på gulvet, tabt i vand eller er blevet beskadiget på en anden måde.
- Hvis produktet, ledningen eller stikket er beskadiget, skal produktet efterses og om nødvendigt repareres af en autoriseret reparatør. Forsøg aldrig at reparere produktet selv. Kontakt købsstedet, hvis der er tale om en reparation, der falder ind under reklamationsretten. Hvis der foretages uautoriserede indgreb i produktet, bortfalder reklamationsretten.

REKLAMATIONSRETEN GÆLDER IKKE:

- Hvis ovennævnte ikke iagttages.
- Hvis der har været foretaget uautoriserede indgreb i produktet.
- Hvis produktet har været misligholdt, udsat for en voldsom behandling eller lidt anden form for overlast.

BORTSKAFFELSE AF PRODUKTET

Brugte produkter må ikke smides i husholdningsaffaldet. Iht. lovforskrifterne skal det udtjente produkt bortskaffes på ordentlig vis. Derved genanvendes de brugbare materialer, og miljøet skånes. Nærmere informationer fås hos den ansvarlige kommunale myndighed eller det lokale bortskaffelsesfirma. Produktet er forsynet med følgende logo:



VIGTIGE SIKKERHEDSANVISNINGER

ADVARSEL: Hvis døren eller dørforseglingerne er beskadigede, må mikrobølgeovnen ikke bruges, før den er repareret af en kvalificeret person.

ADVARSEL: Det er farligt for alle andre end kvalificerede fagpersoner at udføre service eller reparation, der indebærer fjernelse af det dæksel, der yder beskyttelse mod udsættelse for mikrobølgeenergi. ADVARSEL: Væske eller andre former for mad må ikke opvarmes i tillukkede beholdere, da der er fare for, at de eksploderer.

1. Brug kun køkkengrej, der er beregnet til brug i mikrobølgeovne.
2. Metalbeholdere til mad og drikkevarer kan ikke bruges i mikrobølgeovne.
3. Når du opvarmer mad i plast- eller papirbeholdere, skal du holde mikrobølgeovnen under opsyn af hensyn til muligheden for antændelse.
4. Mikrobølgeovnen er beregnet til opvarmning af mad- og drikkevarer. Tørring af madvarer eller beklædning og opvarmning af varmpuder, slippers, svampe, fugtige klude og lignende kan medføre risiko for personskade, antændelse eller ildebrand.
5. Hvis der kommer røg fra mikrobølgeovnen, skal du slukke for apparatet eller trække strømkablet ud af stikkontakten. Hold døren lukket for at kvæle eventuelle flammer. Opvarmning af drikkevarer i en mikrobølgeovn kan resultere i forsinket kogning med opsprøjt, og der skal derfor udvises forsigtighed, når beholderen håndteres.
6. Indholdet i sutteflasker og glas med babymad skal omrøres eller omrystes, og temperaturen skal kontrolleres, før maden indtages, for at undgå forbrændinger.
7. Hele æg med skal og hårdkogte æg må ikke opvarmes i mikrobølgeovnen, da de kan eksplodere, selv efter at opvarmningen i mikrobølgeovnen er slut.
8. Manglende rengøring af mikrobølgeovnen kan føre til ødelæggelse af overfladen, hvilket muligvis kan påvirke ovnens levetid negativt og resultere i en farlig situation. Mikrobølgeovnen fås til fritstående brug, til indbygning eller som skabstype.
9. Apparatet må ikke placeres i et skab.
10. Vær omhyggelig med ikke at skubbe til drejetallerkenen, når du tager beholdere ud af apparatet.
11. Apparatet må ikke rengøres med damp.

Advarsel: Når kombinationsprogrammet på apparatet bruges, må børn kun bruge ovnen under tilsyn af en voksen på grund af de opnåede temperaturer.



FORSIGTIG: VARM OVERFLADE

12. Hvis strømkablet er beskadiget, skal det udskiftes af producenten eller dennes serviceagent eller en lignende kvalificeret person for at undgå fare.
13. Hæld ikke koldt vand direkte på glastallerkenen efter brug. Lad glastallerkenen køle af i mindst 20 minutter, før du lægger den i vand, for at undgå, at den revner.
14. Børn må kun udføre rengøring og brugervedligeholdelse under opsyn.
15. Apparat i gruppe 2, klasse B Gruppe 2, ISM-udstyr: Gruppe 2 indeholder alt ISM-udstyr, hvor radiofrekvensenergi bevidst genereres og/eller bruges i form af elektromagnetisk stråling til behandling af materiale, samt EDM og udstyr til lysbuesvejsning. Udstyr i klasse B er udstyr, der er egnet til brug i husholdninger og steder, der direkte er tilsluttet et netværk med lav spænding, der forsyner bygninger, der bruges til

boligformål.

16. Den interne LED-lyskilde har en lysstrøm på mindre end 60 lm.
17. For at overholde EN 61000-3-11, skal produktet kun tilsluttes et forsyningsystem med en impedans $\leq 0,40089$ ohm. Før produktet tilsluttes det offentlige elnet, bedes du kontakte din lokale elforsyningsmyndighed for at sikre, at netværket opfylder ovenstående krav.
18. Efter at være blevet tilsluttet eller efter at driften er afsluttet, går apparatet i slukket tilstand. Strømforbrug i slukket tilstand: $< 0,3$ W.

INSTALLATION

1. Fjern al emballagen. Fjern eventuel sikkerhedsfilm fra mikrobølgeovnen før brugen. Kontrollér mikrobølgeovnen for eventuelle skader. Hvis du konstaterer skader, skal du straks underrette din forhandler eller aflevere mikrobølgeovnen til producentens servicecenter.
2. Mikrobølgeovne skal anbringes i tørre og ikke-ætsende omgivelser samt holdes væk fra varme og fugtighed som f.eks. gasbrændere og vandtanke.
3. For at sikre tilstrækkelig ventilation skal afstanden mellem væggen og bagsiden af mikrobølgeovnen være mindst 10 cm. Der skal være mindst 5 cm mellem siderne på ovnen og væggen, og frirummet over mikrobølgeovnen skal være mindst 20 cm. Mikrobølgeovnen skal anbringes mindst 85 cm over gulvet. Det minimale frirum over mikrobølgeovnen: 10 cm.
4. Ovnen skal placeres så langt fra tv, radio eller antenner som muligt for at undgå billedforstyrrelser, eller at der opstår støj. Afstanden skal være over 5 m.
5. Apparatet skal placeres, så det er nemt at komme til stikket, og der skal være en forsvarlig jordforbindelse for at undgå elektrisk stød.
6. Når mikrobølgeovnen bruges, skal døren være lukket.
7. Mikrobølgeovnen må ikke placeres i et skab. Mikrobølgeovnen er beregnet til fritstående brug.
8. På grund af rester eller olie fra produktionen i ovnrummet eller på varmeelementet kan ovnen lugte eller udsende lidt røg. Det er normalt og sker kun de første gange, når ovnen tages i brug. Åbn en dør eller et vindue for at sikre god ventilation. Det anbefales kraftigt at anbringe en kop vand i ovnrummet og lade mikrobølgeovnen køre med høj effekt nogle gange.

RENGØRING

PLEJE AF MIKROBØLGEOVN

FORSIGTIG

Mikrobølgeovnen skal rengøres regelmæssigt, og eventuelle madrester fjernes.

ADVARSEL

- a. Træk strømkablet ud af stikkontakten før rengøring. Nedsænk ikke mikrobølgeovnen vand eller andre væsker under rengøringen.
- b. Hvis ovnen ikke holdes ren, kan det medføre forringelse af overfladen, hvilket kan forkorte apparatets levetid og potentielt skabe en farlig situation.
- c. Brug aldrig hårde rengøringsmidler, benzin, skurepulver eller metalbørster til rengøring af mikrobølgeovnen eller dele heraf.
- d. Fjern ikke bølgeafdækningen.
- e. Mikrobølgeovnen kan muligvis begynde at lugte, når den har været brugt i længere tid. Følg én af disse 3 metoder til at fjerne lugten:
 - 1) Læg nogle citronskiver i en kop, og opvarm derefter ved høj effekt i 2-3 minutter.
 - 2) Anbring en kop rød te i mikrobølgeovnen, og opvarm derefter teen ved høj effekt.
 - 3) Læg lidt appelsinskræl i mikrobølgeovnen, og opvarm derefter skrællen ved høj effekt i 1 minut.
- f. Anbring mikrobølgeovnen et sted, der er tørt og udluftet så godt som muligt, når ovnen ikke bruges.



ADVARSEL

Sådan rengøres overflader, der har været i kontakt med mad:
Tør bølgeafdækningen af efter brug med en fugtig klud. Tør efter med en tør klud for at fjerne eventuelle madsprøjt og fedt. Ophobet fedt kan overophedes og begynde at ose eller gå i brand.

TIPS TIL RENGØRING

Udvendige overflader:

Aftør den ydre kapsling med en blød klud fugtet med vand.

Dør:

Tør døren og vinduet af med en blød, fugtig klud.

Rengør dørtætningerne og de tilstødende områder for at fjerne eventuelle spild eller sprøjt.

Tør betjeningspanelet forsigtigt af med en let fugtet blød klud.

Indvendige overflader:

Tør de indvendige overflader af med en blød, fugtig klud.


Rengør bølgeledningsdækslet for at fjerne eventuelle madstænk.

Glastallerken/rullestøtte/aksel:

Vask med mildt sæbevand.

Skyl med rent vand, og lad alle dele tørre grundigt, før de geninstalleres.

PRODUKTVEJLEDNING



1. Knap til åbning af dør
Døren til mikrobølgeovnen skal være korrekt lukket, for at ovnen kan fungere.
2. Ovnvindue
Gør det muligt at se tilberedningsstatus.
3. Aksel
Glasdrejetallerkenen sidder på akslen. Motoren nedenunder får tallerkenen til at dreje rundt.
4. Drejetallerken
Maden ligger på drejetallerkenen, som roterer for at maden bliver jævnt tilberedt.
5. Rullestøtte
Glasdrejetallerkenen ligger på hjulene; ringen understøtter drejetallerkenen og hjælper den med at holde balancen, når den roterer.


FORSIGTIG

- Placér først rullestøtten.
 - Læg drejetallerkenen på akslen, og sørg for, at den ligger korrekt.
6. Kontrolpanel
Se herunder for detaljer (ret til uvarslet ændring i kontrolpanelets udformning forbeholdes).
 7. Bølgeafdækning
Findes inde i mikrobølgeovnen ved siden af væggen med kontrolpanelet.

ADVARSEL

Fjern aldrig bølgeafdækningen.

BETJENING AF KONTROLPANEL



1. INDSTILLING AF UR

Den maksimale timerindstilling er 35 minutter. Når den indstillede tid er udløbet, vil en ringtone lyde, og knappen vil automatisk vende tilbage til positionen "0".

2. MIKROBØLGEPROGRAM

Nr.	MIKROBØLGEVNEENS EFFEKT	MIKROBØLGE UDFØRSELSFORHOLD
1	Lav	Omkring 17 % effekt
2	Optøning/M.Lav	Omkring 30 % effekt
3	Med.	Omkring 55 % effekt
4	M.høj	Omkring 80 % effekt
5	Høj	100 % effekt

Her følger nogle råd om optøningstid for visse fødevarer:

Nr.	Vægt (g)	Optøningstid
1	200 g	Omkring 4 minutter
2	400 g	Omkring 8 minutter
3	600 g	Omkring 12 minutter

BETJENING

1. Sæt stikket i stikkontakten

Før tilslutning af ledningen skal du sikre dig, at timeren er indstillet til positionen "0".
Dæk ikke ventilationsåbningerne.

2. Placer maden

Placer maden på glasdrejeskiven, og luk døren sikkert.

Maden skal placeres i en egnet, mikrobølgeovnssikker beholder.

Betjen ikke mikrobølgeovnen uden mad indeni (ingen belastning), da dette kan forårsage skade på apparatet.

3. Vælg effekttrin

Vælg det ønskede effektniveau for mikrobølgeovnen ud fra dine tilberedningsbehov.

4. Start betjening

Mikrobølgeovnen vil begynde at køre.

For at sætte i pause under drift, åbn døren når som helst. Luk døren for at genoptage driften.

5. Slut på tilberedning

Når den indstillede tid er udløbet, vil en klokke ringe, og det indvendige lys vil automatisk slukke.

Hvis maden fjernes, før timeren udløber, skal du sørge for at sætte timeren tilbage til positionen "0". Dette forhindrer, at mikrobølgeovnen kører uden belastning.

6. Fjern tilberedt mad sikkert

Det anbefales at bruge ovnhandsker, når du fjerner tilberedt mad.

Vær forsigtig med ikke at røre ved de indvendige vægge i kammeret, da de kan være varme.



FORSIGTIG

Mad kan opvarmes hurtigt, normalt inden for 2–3 minutter. Opvarm ikke i mere end 5 minutter kontinuerligt.

Overvåg altid tilberedningsprocessen, og juster opvarmningstiden efter din smag og typen af mad. Undgå overophedning.

Når du varmer grød eller congee, rør godt rundt før opvarmning. Dæk med plastfolie (lad et hjørne være åbent for ventilation), eller brug et låg med små huller, så dampen kan slippe ud.

Under optøning skal døren åbnes halvvejs gennem optøningstiden, og maden skal vendes for at sikre et mere jævnt resultat.

ANVISNINGER FOR KØKKENREDSKABER

Det anbefales kraftigt, at du anvender beholdere, der er egnede og sikre til brug i mikrobølgeovn. Generelt skal beholderne være fremstillet i varmebestandig keramik, glas eller plast for at være egnede til brug i mikrobølgeovn. Brug aldrig metalbeholdere ved tilberedning med mikrobølger eller kombinationstilberedning, da der kan opstå gnister. Brug vejledningen i følgende tabel.

Beholdermateriale	Mikroovn	Noter
Varmebestandig keramik	Ja	Brug aldrig keramik, der er udsmykket med metalkant eller er glaseret Det anbefales at bruge keramiske beholdere, varmebestandigt glas eller plastbeholdere, der kan tåle temperaturer over 120 °C.
Varmeresistent plast	Ja	Kan ikke bruges ved lang tilberedning i mikrobølgeovn
Varmebestandigt glas	Ja	
Plastfolie	Ja	Bør ikke anvendes ved tilberedning af kød eller koteletter, da den ekstrahøje temperatur kan beskadige plastfolien
Grillrist	Nej	

TILBEREDNINGSTIPS

Følgende faktorer kan påvirke tilberedningsresultatet:

Placering af madvarerne

Læg tykkere stykker yderst på tallerkenen og tyndere stykker ind mod midten, og bred maden jævnt ud. Maden må helst ikke overlappe.

Tilberedningstid

Start tilberedningen med en kort tidsindstilling, kig dernæst til maden, og indstil tilberedningstiden efter det faktiske behov. For lang tilberedning kan medføre røg og forkulning.

Tilbered maden jævnt

Madvarer som kylling, hamburger eller bøf bør vendes en gang under tilberedningen.

Hvis typen af madvarer kræver omrøring, så rør fra siden af tallerkenen og ind mod midten en eller to gange i løbet af tilberedningen

Lad maden stå lidt

Efter tilberedningen skal maden have lov at stå i ovnen i passende tid for at færdiggøre tilberedningen og køle gradvist ned

Tjek, om maden er færdig

Madvarernes farve og hårdhed hjælper med at afgøre, om maden er færdig. Dette omfatter:

- Når der kommer damp fra alle dele af maden, ikke kun kanten
- Når fjerkræ skiller let i leddene
- Når svinekød eller kylling ikke viser tegn på blod
- Når fisk er uigennemsigtig og let kan skæres med en gaffel

Bruningstallerken

Hvis du anvender en bruningstallerken eller selvvarmende beholder, skal du altid placere en varmebestandig isolator, som fx en porcelænstallerken, under den for at undgå

beskadigelse af drejetallerkenen eller rullestøtten.

Mikrobølgesikker plastfolie

Når du tilbereder madvarer med højt fedtindhold, bør du ikke lade plastfolie komme i kontakt med maden, da folien kan smelte

Mikrobølgesikre køkkenredskaber

Visse mikrobølgesikre køkkenredskaber er muligvis ikke egnede til tilberedning af madvarer med højt fedt- og sukkerindhold. Desuden må den forvarmningstid, der er angivet for retten i vejledningen, ikke overskrides.

SERVICEANVISNINGER

Forsigtig: MIKROBØLGESTRÅLING

1. Højspændingskondensatoren er fortsat strømførende efter afbrydelse. Kortslut den negative terminal på højspændingskondensatoren på ovnchassiset (med en skruetrækker) for at aflade kondensatoren før berøring.
2. De nedenfor anførte dele skal fjernes under service og giver adgang til elektriske strømkabler med over 250 V.
 - Magnetron
 - Højspændingstransformer
 - Højspændingskondensator
 - Højspændingsdiode
 - HøjspændingssikringDen faktiske konfiguration af produktet kan variere.
3. Følgende forhold kan forårsage unødvendig eksponering for mikrobølger under service.
 - Forkert installation af magnetron.
 - Sikkerhedslås, dørhængsel og dør passer ikke sammen.
 - Forkert installation af kontaktstøtte.
 - Dør, dørforselinger eller kabinet er beskadiget.

TEKNISKE DATA

Artikelnr. 11165137
220-240V~, 50/60Hz
Output power: 700 Watt
Nominel indgangseffekt:
1100 Watt

PRODUCENT

Epiq ApS
Krøyer Kielbergs Vej 3, 3. th
8660 Skanderborg, Danmark
www.epiq.dk

Vi tager forbehold for trykfejl.

INTRODUCTION

Thank you for choosing a product from K kkenchef. You have acquired a quality product which meets all applicable performance and safety standards in the EU. In order to ensure proper treatment and a long product life, we recommend that you comply with the instructions below.

Please read the manual and especially the safety instructions carefully before using the product. Keep this manual and provide it for referral along with the product when others are using it.

GENERAL SAFETY INSTRUCTIONS

- Improper use of the product can cause personal injury and damage.
- Only use the product for what it is intended. The manufacturer is not liable for damages arising from improper use or handling.
- Always place the product on a dry, flat and stable surface well away from table edge or similar.
- The product is intended for household use only. The product is not for professional use.
- The product may only be connected to 220-240V~, 50/60Hz.
- The product engine/electronics, cord or plug cannot be submerged in water, and no water may get in contact with the engine/electronics.
- Never touch the product, cord or plug with wet or damp hands.
- Do not expose the product to direct sunlight, high temperatures, humidity, dust or corrosive substances.
- Never leave the product when it is turned on.
- When the product is in use, it should be kept under constant supervision. Children should always be supervised when using the product to ensure that they do not play with the product. The product is not a toy.

- The product may have sharp parts and must, therefore, be kept out of reach of children.
- Only use the accessories that come with the product or that are recommended by the manufacturer.
- This product can be used by children aged from 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the product in a safe way and understand the hazards involved.
- Keep the product and its cord out of reach of children less than 8 years of age.
- Cleaning and user maintenance shall not be made by children without supervision.

CORD AND PLUG

- Do not let the cord hang over the edge.
- Keep the cord and the product away from heat sources, hot objects and open flames.
- Unplug the power cord before cleaning and if the product is not in use. Do not pull the cord when removing the plug from the socket, rather grasp the plug itself.
- Make sure that the cord is fully extended.
- Check regularly that the cord and the plug are not damaged and do not use the product if this is the case, or if it has been dropped on the floor, dropped in water or damaged in another way.
- If the product or plug is damaged, the product must be inspected and, if necessary, repaired by an authorised repairer. Never try to repair the product yourself. Please, contact the store to see if there is a repair that falls under warranty. Tampering of the product will void the warranty.

RULES OF COMPLAINTS THE WARRANTY DOES NOT APPLY:

- If the above is not observed.
- If there has been unauthorised intervention of the product.

- If the product has been mishandled, subjected to rough treatment or some other form of damage.

PRODUCT DISPOSAL

Used product should not be disposed as household waste. According to legislation, the product should be disposed of properly so that the materials can be recycled in an environmentally friendly manner. Further information is available from the responsible local authority or local disposal company. The product is equipped with the following logo:



IMPORTANT SAFEGUARDS

WARNING: If the door or door seals are damaged, the microwave oven must not be operated until it has been repaired by a trained person.

WARNING: It is hazardous for anyone other than a trained person to carry out any service or repair operation, which involves the removal of any cover, which gives protection against exposure to microwave energy. WARNING: Liquids or other food must not be heated in sealed containers since they are liable to explode.

1. Only use utensils that are suitable for use in microwave ovens
2. Metallic containers for food and beverages are not allowed during microwave cooking.
3. When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition
4. The microwave oven is intended for heating food and beverages. Drying of food or clothing and heating of warming pads, slippers, sponges, damp cloth and similar may lead to risk of injury, ignition, or fire.
5. If smoke is observed, switch off or unplug the appliance and keep the door closed in order to stifle any flames microwave heating of beverages can result in delayed eruptive boiling, therefore care has to be taken when handling the container;
6. The contents of feeding bottles and baby food jars are to be stirred or shaken and the temperature is to be checked before consumption, to avoid burns.
7. Eggs in their shell and whole hardboiled eggs shall not be heated in microwave ovens since they may explode, even after microwave heating has ended.
8. Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.
9. The appliance must not be placed in a cabinet
10. Care should be taken not to displace the turntable when removing containers from the appliance.
11. The appliance shall not be cleaned with a steam cleaner.

Warning: When the appliance is operated in the combination mode, children should only use the oven under adult supervision due to the temperatures generated.



CAUTION: HOT SURFACE

12. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person to avoid a hazard.
13. Do not pour cold water directly onto the glass plate after use. Allow the glass plate to cool for at least 20 minutes before placing it in water to prevent cracking.
14. Cleaning and user maintenance shall not be made by children without supervision.
15. Group 2 Class B appliance

Group 2 ISM equipment: group 2 contains all ISM equipment in which radio-frequency energy is intentionally generated and/or used in the form of electromagnetic radiation for the treatment of material, and EDM and arc welding equipment.

Class B equipment is equipment suitable for use in domestic establishments and in establishments directly connected to a low voltage power supply network which

supplies buildings used for domestic purposes.

16. The internal LED light source has a luminous flux of less than 60 lm.
17. To comply with EN 61000-3-11, the product shall be connected only to a supply system with an impedance of ≤ 0.40089 ohms. Before connecting the product to the public power network, please consult your local power supply authority to ensure that the network meets the above requirement.
18. After being plugged in or after operation is completed, the appliance enters Off mode. Off mode power consumption: < 0.3 W.

INSTALLATION

1. Take out all the packing. If there is a safe film over the oven, tear it off before use. Check carefully for damage. If any, immediately notify dealer or send to the manufacturer's service center.
2. Microwave ovens must be placed under dry and non-corrosiveness environments, kept away from heat and humidity, such as gas burner or water tank.
3. To ensure sufficient ventilation, the distance of the back of the microwave to the wall should be at least 10 cm, the side to the wall should be at least 5 cm, the free distance above the top surface at least 20 cm. the distance of the microwave to the ground should be at least 85 cm. Minimum height of free space necessary above the top surface of the oven: 100mm.
4. The position of the oven shall be such that it is far from the TV, Radio or antenna as picture disturbance, or noise may occur. The distance should be more than 5m.
5. The appliance must be positioned so that the plug is accessible, and must ensure a good grounding in case leakage, ground loop can be formed to avoid electric shock.
6. The microwave oven must be operated with the door closed.
7. The microwave oven must not be placed in a cabinet. The microwave oven is intended to be used freestanding.
8. As there is manufacturing residue or oil remained on the oven cavity or heat element, it usually would smell the odor, even a slight smoke, It is normal case and would not occur after several times use, keep the door or window open to ensure good ventilation. It is strongly recommended to place a cup of water in the cavity, setting at high power and operate for several times.

CLEANING

MICROWAVE OVEN CARE



CAUTION

The microwave oven should be cleaned regularly and any food deposits removed.



WARNING

- a. Remove the power cord from the wall outlet before cleaning. Do not immerse the appliance in water or other fluids when cleaning.
- b. Failure to keep the oven clean may cause surface deterioration, which could reduce

the appliance's lifespan and potentially create a hazardous situation.

- c. Never use hard detergent, gasoline, abrasive powder, or metal brush to clean any part of the appliance.
- d. Do not remove the waveguide cover.
- e. When the microwave oven has been used for a long time, orders may start to appear in the microwave oven. Following one these 3 methods can get rid of them:
 - 1) Place several lemon slices in a cup, then heat with high Micro Power for 2-3 min.
 - 2) Place a cup of red tea in oven, then heat with high micro power.
 - 3) Put some orange peel into microwave oven, and then heat them with high Micro Power for 1 minute.
- f. When the product is not used, it should be placed in try and ventilated areas as well as possible.

WARNING

Details how to clean surfaces in contact with food:

After use wipe the waveguide cover with a damp cloth, followed by dry cloth to remove any food splashes and grease. Built -up grease may overheat and begin to cause smoke or catch fire.

TIPS FOR CLEANING

Exterior:

Wipe the outer enclosure with a soft cloth dampened with water.

Door:

Wipe the door and window with a soft, damp cloth.

Clean the door seals and adjacent areas to remove any spills or splatters.

Wipe the control panel gently with a slightly damp soft cloth.

Interior Walls:

Wipe the interior surfaces with a soft, damp cloth.


Clean the waveguide cover to remove any food splashes.

Turntable / Rotation Ring / Rotation Axis:

Wash with mild soapy water.

Rinse with clean water and allow all parts to dry thoroughly before reinstalling.

PRODUCT INSTRUCTION



1. Door lock

Microwave oven door must be properly closed for it to operate.

2. Viewing window

Allow user to see the cooking status.

3. Rotating ring

The glass turntable sits on its wheels; it supports the turntable and helps it to balance when rotating.

4. Rotating axis

The glass turntable sits on the axis; the motor underneath it drives the turntable to rotate.

5. Turntable

The food sits on the turntable, its rotation during operation helps to cook food evenly.

 **CAUTION**

- Place the rotating ring first
- Fit the turntable onto the rotating axis and make sure that it is geared in properly

6. Control panel

See below in details (the control panel is subject to change without prior notice)


7. Waveguide cover

It is inside the microwave oven, next to the wall of the control panel.

 **WARNING**

Never remove the waveguide cover

OPERATION OF CONTROL PANEL



1. CLOCK SETTING

The maximum timer setting is 35 minutes. When the set time has elapsed, a ringtone will sound, and the knob will automatically return to the "0" position.

2. MICROWAVE FUNCTION

No.	MICROWAVE POWER	MICROWAVE OUTPUT RATIO
1	Low	About 17% power output
2	Defrost/M.Low	About 30% power output
3	Med	About 55% power output
4	M.High	About 80% power output
5	High	100% power output

Below is some food defrosting time advice:

No.	Weight (g)	Defrost time
1	200g	About 4 minutes
2	400g	About 8 minutes
3	600g	About 12 minutes

OPERATION

1. Connect the Power Cord

Before connecting the cord, ensure the timer is set to the "0" position.

Do not block the ventilation openings.

2. Place the Food

Place the food on the glass turntable tray and close the door securely.

Food must be placed in a suitable, microwave-safe utensil.

Do not operate the microwave oven without any food inside (no-load operation), as this may cause damage to the appliance.

3. Select Power Level

Choose the desired microwave power level according to your cooking requirements.

4. Start Operation

The microwave oven will begin running.

To pause during operation, open the door at any time. Close the door to resume operation.

5. End of Cooking

When the set time has elapsed, a bell will ring, and the interior lamp will turn off automatically.

If food is removed before the timer expires, be sure to return the timer to the "0" position.

This prevents the microwave from operating with an empty load.

6. Remove Cooked Food Safely

It is recommended to wear oven gloves when removing cooked food.

7. Be careful not to touch the inner walls of the cavity, as they may be hot.

CAUTION

Food can be heated quickly, usually within 2 to 3 minutes. Do not heat for more than 5 minutes continuously.

Always monitor the cooking process and adjust the heating time according to your taste and the type of food. Avoid overheating.

When heating porridge or congee, stir well before heating. Cover with plastic wrap (leaving a corner open for ventilation) or use a lid with small holes to allow steam to escape.

During defrosting, open the door halfway through the defrosting time and turn the food over to ensure more even results.

UTENSILS GUIDELINE

It is strongly recommended to use the containers which are suitable and safe for microwave cooking. Generally speaking, the containers which are made of heat-resistant ceramic, glass or plastic are suitable for microwave cooking. Never use the metal containers for microwave cooking and combination cooking as spark is likely to occur. You can take the reference of below table.

Material of container	Microwave	Notes
Heat-resistant ceramic	Yes	Never use the ceramics which are decorated with metal rim or glazed. It is recommended to use ceramic, heat-resistant glass, or plastic containers that can withstand temperatures above 120 °C.
Heat-resistant plastic	Yes	Cannot be used for long time microwave cooking
Heat-resistant glass	Yes	
Plastic film	Yes	It should not be used when cooking meat or chops as the over-temperature may do damage to the film
Grill rack	No	

COOKING TIPS

The following factors may affect the cooking result:

Food arrangement

Place thicker areas towards outside of dish, the thinner part towards the centre and

spread it evenly. Do not overlap if possible.

Cooking time length

Start cooking with a short time setting, evaluate it after it times out and extend it according to the actual need. Over cooking may result in smoke and burns.

Cooking food evenly

Food such as chicken, hamburger or steak should be turned once during cooking.

Depending on the type of food, if applicable, stir it from outside to centre of dish once or twice during cooking

Allow standing time

After cooking times out, leave the food in the oven for an adequate length of time, this allows it to complete its cooking cycle and cooling it down in a gradual manner

Whether the food is done

Color and hardness of food help to determine if it is done, these include:

- Steam coming out from all parts of food, not just the edge
- Joints of poultry can be moved easily
- Pork or poultry shows no signs of blood
- Fish is opaque and can be sliced easily with a fork

BROWNING DISH

When using a browning dish or self-heating container, always place a heat-resistant insulator such as a porcelain plate under it to prevent damage to the turntable and rotating ring.

MICROWAVE SAFE PLASTIC WRAP

When cooking food with high fat content, do not allow the plastic wrap come into contact with food as it may melt

MICROWAVE SAFE PLASTIC COOKWARE

Some microwave safe plastic cookware might not be suitable for cooking foods with high fat and sugar content. Also, the preheating time specified in the dish instruction manual must not be exceeded.

MAINTENANCE

SERVICING SAFEGUARDS

Caution: MICROWAVE RADIATION

1. The high voltage capacitor remains charge after disconnection; short the negative terminal of H. V capacitor to the oven chassis (use a screwdriver) to discharge before touching.
2. During servicing below listed parts are liable to be removed and give access to potentials above 250V to earth.
 - Magnetron
 - High voltage transformer
 - High voltage capacitor
 - High voltage diode

- High voltage fuse
The actual configuration of the product may vary.
- 3. The following conditions may cause undue microwave exposure during servicing.
 - Improper fitting of magnetron.
 - Improper matching of the door interlock, door hinge and door.
 - Improper fitting of switch support.
 - Door, door seal or enclosure has been damaged.

TECHNICAL DATA

Article No. 11165137

220-240V~, 50/60Hz

Output power: 700 Watt

Rated Input Power: 1100 Watt

PRODUCER

Epiq ApS

Krøyer Kielbergs Vej 3, 3. th

8660 Skanderborg, Denmark

www.epiq.dk

We cannot be held responsible for any printing errors.